

C.A 6165



Appliance multitester





About the user's manual

- > This Instruction manual contains detailed information on the C.A 6165, its key features, functionalities and use.
- It is intended for technically qualified personnel responsible for the product and its use.
 Please note that LCD screenshots in this document may differ from the actual instrument screens in details due to firmware variations and modifications.

Contents

1	General description	6
	1.1 Warnings and notes	6
	1.1.1 Safety warnings	6
	1.1.2 Warnings related to safety of measurement functions	
	1.1.3 Markings on the instrument	
	1.2 Standards applied Erection and operation of electrical test equipment	
2	Instrument set and accessories	9
	2.1 Standard set of the instrument	
	2.2 Optional accessories	9
3	Instrument description	10
	3.1 Front panel	10
4	Instrument operation	11
	4.1 General meaning of keys	11
	4.2 General meaning of touch gestures:	
	4.3 Safety checks	
	4.4 Symbols and messages	
	4.5 Instrument main menu	
	4.6 General settings	
	4.6.1 Language 4.6.2 Date and time	
	4.6.3 Profiles	
	4.6.4 Workspace Manager	
	4.6.5 Auto Śequence [®] groups	
	4.6.6 User accounts	
	4.6.7 Change password for HV functions	
	4.6.8 Settings 4.6.9 Devices	
	4.6.9 Devices	
	4.6.11 About	
	4.7 Instrument profiles	
	4.8 Workspace Manager	
	4.8.1 Workspaces and Exports	
	4.8.2 Workspace Manager main menu 4.9 Auto Sequence [®] groups	
	4.9 Auto Sequence [®] groups 4.9.1 Auto Sequence [®] groups menu	
_		
5	Memory Organizer	
	5.1 Memory Organizer menu	
	5.1.1 Measurement statuses	
	 5.1.2 Structure Objects 5.1.3 Selecting an active Workspace in Memory Organizer 	
	5.1.4 Adding Nodes in Memory Organizer	
	5.1.5 Operations in Tree menu	
	5.1.6 Searching in Memory Organizer	53
6	Single tests	57
	6.1 Selection of single tests	57
	6.1.1 Single test screens	59
	6.1.2 Single test (inspection) screens	
	6.1.3 Help screens	
	6.2 Single test measurements	
	6.2.1 Visual inspections 6.2.2 Continuity	
	6.2.3 HV AC	
	6.2.4 HV DC	
	6.2.5 HV AC programmable	
	6.2.6 HV DC programmable	
	6.2.7 Insulation resistance (Riso, Riso-S)	78

	6.2.8	Sub-leakage (Isub, Isub-S)	
	6.2.9	Differential Leakage	
	6.2.1 6.2.1		
	6.2.1	5	
	6.2.1		
	6.2.1	4 Discharging Time	
	6.2.1	5 Functional inspections	
7	Αι	to Sequences [®]	
	7.1	Selection of Auto Sequences [®]	05
	7.1.1	Selection of Auto Sequences	
	7.1.2	Searching in Auto Sequences [®] menu	
	7.1.3	Structure organization of Auto Sequence® group	
	7.2	Organization of Auto Sequence® tests	
	7.2.1 7.2.2	Auto Sequence [®] view menu Step by step excecution of Auto Sequences®	
	7.2.2	Auto Sequence [®] result screen	
	7.2.4	Auto Sequence [®] memory screen	
8	Ma	intenance	
0	IVIC		
	8.1	Periodic calibration	
	8.2	Fuses	
	8.3 8.4	Service	
_	-	•	
9	Co	mmunications	107
	9.1	USB and RS232 communication with PC	
	9.2	Bluetooth communication	
	9.3	Bluetooth communication with printers and scanners	
	9.4 9.5	Ethernet communication RS232 communication with other external devices	
	9.5 9.6	Connections to test adapters.	
	9.6.1		
	9.7	INPUTs	
	9.8	OUTPUTs	110
10) Te	chnical specifications	111
	10.1	HV AC, HV AC programmable	111
	10.1	HV DC, HV DC programmable	
	10.3	Continuity	112
	10.4	Insulation Resistance, Insulation Resistance-S	
	10.5	Substitute Leakage Current, Substitute Leakage Current - S	
	10.6	Differential Leakage current PE leakage current	
	10.7 10.8	Touch leakage current	
	10.9	Power	
	10.10	Leak's & Power	115
	10.11	Discharging time	
	10.12	General data	
A	ppendix /	4 - Structure objects in C.A 6165	119
Α	opendix	3 - Profile Notes	
A	ppendix	C - Print labels and write / read RFID / NFC tags	
	C.1	PAT tag format	
	C.2	Generic tag format	121
A	ppendix	D - Default list of Auto Sequences [®]	123
		E - Programming of Auto Sequences® on MT Link	
A			
	E.1	Auto Sequence® Editor workspace	
	E.2	Managing of Auto Sequence® groups	
	E.2.1 E.2.2		
	E.3	Elements of an Auto Sequence [®]	

E.3.1	Auto Sequence [®] steps	
E.3.2	Single tests	
E.3.3	Flow commands	
E.3.4	Number of measurement steps	
	Creating / modifying an Auto Sequence®	
	Description of flow commands	
	Custom Inspections programming	
	Creating and editing Custom Inspections	
	Applying Custom Inspections	

1.1 Warnings and notes



1.1.1 Safety warnings

In order to reach high level of operator safety while carrying out various measurements using the C.A 6165 instrument, as well as to keep the test equipment undamaged, it is necessary to consider the following general warnings:

- Read this Instruction manual carefully, otherwise use of the instrument may be dangerous for the operator, for the instrument or for the equipment under test!
- · Consider warning markings on the instrument!
- If the test equipment is used in manner not specified in this Instruction manual the protection provided by the equipment may be impaired!
- > Do not use the instrument and accessories if any damage is noticed!
- Regularly check the instrument and accessories for correct functioning to avoid hazard that could occur from misleading results.
- Consider all generally known precautions in order to avoid risk of electric shock while dealing with hazardous voltages!
- Use only standard or optional test accessories supplied by your distributor!
- Only test adapters provided or approved by Chauvin Arnoux should be connected to TC1 (test and communication) connectors.
- Use only earthed mains outlets to supply the instrument!
- In case a fuse has blown refer to chapter 8.2 Fuses in this Instruction manual to replace it!
- Instrument servicing and calibration is allowed to be carried out only by a competent authorized person!
- Chauvin Arnoux is not responsible for the content of the user-programmed Auto Sequences®!

1.1.2 Warnings related to safety of measurement functions

1.1.2.1 HV AC, HV DC, HV AC programmable, HV DC programmable

- A dangerous voltage up to 5 kV_{AC} or 6 kV_{DC} is applied to the HV instrument outputs during the test. Therefore special safety consideration must be taken when performing this test!
- Only a skilled person familiar with hazardous voltages can perform this measurement!
- > DO NOT perform this test if any damage or abnormality (test leads, instrument) is noted!
- Never touch exposed probe tip, connections equipment under test or any other energized part during the measurements. Make sure that NOBODY can contact them either!

- DO NOT touch any part of test probe in front of the barrier (keep your fingers behind the finger guards on the probe) possible danger of electric shock!
- It is a good practice to use lowest possible trip-out current.

1.1.2.2 Diff. Leakage, Ipe Leakage, Touch Leakage, Power, Leak's & Power

Load currents higher than 10 A can result in high temperatures of fuse holders and On/Off switch! It is advisable not to run tested devices with load currents above 10 A for more than 15 minutes. Recovery period for cooling is required before proceeding with tests! Maximum intermittent duty cycle for measurements with load currents higher than 10 A is 50 %.

1.1.2.3 Insulation resistance

Do not touch the test object during the measurement or before it is fully discharged! Risk of electric shock!

1.1.3 Markings on the instrument

. 🛕

Read the Instruction manual with special care to safety operation«. The symbol requires an action!

Dangerous high voltage is present on terminals during the test. Consider all precautions in order to avoid risk of electric shock.



C Mark on your equipment certifies that it meets European Union requirements for EMC, LVD, and ROHS regulations.



This equipment should be recycled as electronic waste.

1.2 Standards applied

The C.A 6165 instrument is manufactured and tested according to the following regulations, listed below.

Electromagnetic compatibility (EMC)

IEC 61326-1	Electrical equipment for measurement, control and laboratory use - EMC requirements – Part 1: General requirements Class B (Portable equipment used in controlled EM environments)
Safety (LVD)	
IEC 61010-1	Safety requirements for electrical equipment for measurement, control, and laboratory use – Part 1: General requirements
IEC 61010-2-030	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 2-030: Particular requirements for testing and measuring circuits
IEC 61010-031	Safety requirements for electrical equipment for measurement, control and laboratory use – Part 031: Safety requirements for hand-held probe assemblies for electrical measurement and test
IEC 61557	Electrical safety in low voltage distribution systems up to 1 000 V a.c. and 1 500 V d.c. – Equipment for testing, measuring or monitoring of protective measures Instrument complies with all relevant parts of IEC 61557 standards.

Functionality

IEC 60335	Household and similar electrical appliances
IEC 60950	Information technology equipment – Safety
IEC 61439	Low-voltage switchgear and controlgear assemblies
IEC 61010	Safety requirements for electrical equipment for measurement, control, and laboratory use
IEC 60598	Safety of lighting equipment
VDE 0701-702	Inspection after repair, modification of electrical appliances – Periodic inspection on electrical appliances
	General requirements for electrical safety
IEC 50191	Erection and operation of electrical test equipment

2 Instrument set and accessories

2.1 Standard set of the instrument

- Instrument C.A 6165
- Bag for accessories
- HV test probes 2 m, 2 pcs
- Continuity test lead set 2.5 m, 2 pcs
- Continuity test lead red 1.5 m / 2.5 mm²
- Test lead black 2.5 m
- Test lead red 2.5 m
- Alligator clips black 2 pcs
- Alligator clips red 3 pcs
- Mains cable (2 m, wire cross-section 3 x 1.5 mm²)
- RS232 cable
- USB cable
- Calibration Certificate
- Short form instruction manual
- CD with instruction manual (full version) and PC SW MT Link

2.2 Optional accessories

See the attached sheet for a list of optional accessories that are available on request from your distributor.

3.1 Front panel





Figure 3.1: Front panel

2 F1, F2 fuses (F 5 A / 250 V) 3 F3, F4 fuses (T 16 A / 250 V) 4 On / Off switch 5 Test connections TC1 for external test adapters 6 Mains test socket 7 P/S (probe) connector 8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Control inputs connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector 21 MicroSD card slot	1	Mains supply connector
4 On / Off switch 5 Test connections TC1 for external test adapters 6 Mains test socket 7 P/S (probe) connector 8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	2	F1, F2 fuses (F 5 A / 250 V)
5 Test connections TC1 for external test adapters 6 Mains test socket 7 P/S (probe) connector 8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	3	F3, F4 fuses (T 16 A / 250 V)
6 Mains test socket 7 P/S (probe) connector 8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	4	On / Off switch
7 P/S (probe) connector 8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	5	Test connections TC1 for external test adapters
8 Keypad 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	6	Mains test socket
 9 HV output connectors 10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector 	7	P/S (probe) connector
10 HV output warning lamp 11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	8	Keypad
11 Continuity connectors 12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	9	HV output connectors
12 Insulation / Subleakage connectors 13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	10	HV output warning lamp
13 Discharging time connectors 14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	11	Continuity connectors
14 Colour TFT display with touch screen 15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	12	Insulation / Subleakage connectors
15 Control outputs 16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	13	Discharging time connectors
16 Control inputs 17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	14	Colour TFT display with touch screen
17 Multipurpose RS232-1 port 18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	15	Control outputs
18 Multipurpose RS232-2 port 19 Ethernet connector 20 USB connector	16	Control inputs
19 Ethernet connector 20 USB connector	17	
20 USB connector	18	Multipurpose RS232-2 port
	19	Ethernet connector
21 MicroSD card slot	20	USB connector
	21	MicroSD card slot

The C.A 6165 can be manipulated via a keypad or touch screen.

4.1 General meaning of keys



4.2 General meaning of touch gestures:

J.	Tap (briefly touch surface with fingertip) is used to: - select appropriate option - confirm selected option - start and stop measurements
Jew)	Swipe (press, move, lift) up/ down is used to: - scroll content in same level - navigate between views in same level
	Long press (touch surface with fingertip for at least 1 s) is used to: - select additional keys (virtual keyboard) - enter cross selector from single test screens
J €	 Tap Escape icon is used to: return to previous menu without changes abort measurements


4.3 Safety checks


At start up and during operation the instrument performs various safety checks to ensure safety and to prevent any damage. These safety pre-tests are checking for:

- Correct input mains voltage
- Presence of input PE connection,
- Any external voltage against earth on mains test socket
- Excessive leakage currents through measuring I/Os,
- Too low resistance between L and N of tested device,
- · Proper operation of safety relevant internal electronic circuits

If a safety check fails, an appropriate warning message will be displayed and safety measures will be taken. The warnings and safety measures are described in chapter 4.4 Symbols and messages.

4.4 Symbols and messages





The instrument is overheated. The measurement can't be carried out until the icon disappears. Press OK to continue.
The device under test should be switched on (to ensure that the complete circuit is tested).
Test voltage in Insulation resistance measurement is too low.
Measurement result is scaled to 110 V.
Red dot indicates phase of measurement where higher leakage was measured. Applicable only if phase reversal is enabled during the measurement.
Test leads resistance in Continuity P/S - PE measurement is not compensated.
Test leads resistance in Continuity P/S - PE measurement is compensated.
Warning!
A high voltage is / will be present on the instrument output! (Withstanding test voltage, Insulation test voltage, or mains voltage).
Warning!
A very high and dangerous voltage is / will be present on the instrument output! (Withstanding test voltage).
Test passed.
Test failed.
Conditions on the input terminals allow starting the measurement; consider other displayed warnings and messages.
Conditions on the input terminals do not allow starting the measurement, consider displayed warnings and messages.
Proceeds to next measurement step
Stop the measurement.

4.5 Instrument main menu

Main Menu	10:10
· D	LE I
Single Tests	Memory Organizer
	≊tö
Auto Sequences®	General Settings

From the instrument Main Menu different main operation menus can be selected.

Figure 4.1: Main menu

Options

Single Tests	Single Tests Menu with single tests, see chapter 6 <i>Single tests.</i>
Auto Sequences®	Auto Sequences [®] Menu with customized test sequences, see chapter 7 <i>Auto Sequences</i> ®.
Memory Organizer	Memory Organizer Menu for working with and documentation of test data, see chapter 5 <i>Memory Organizer</i> .
General Settings	General Settings Menu for setup of the instrument, see chapter <i>4.6 General</i> settings.

4.6 General settings

🖆 General Set			General Settings		13:30	
Eanguage	Date / Time	₩orkspace Manager	Let Auto Seq. groups	 User accounts	000 JJJ Profiles	
Let Auto Seq. groups	User accounts	900 JJJ Profiles	े Settings	Ö ÖÖ Devices	Ø ⊕ Initial Settings	
Settings	Contraction Devices	ाnitial Settings	Change password	<i>i</i> About		

In the General Settings menu general parameters and settings of the instrument can be viewed or set.



Options in General Settings menu

C Language	Language Instrument language selection
Date / Time	Date / Time Instruments Date and time.
₩orkspace Manager	Workspace Manager Manipulation with project files. Refer to chapter 4.8 Workspace Manager for more information.
Let Auto Seq. groups	Auto Sequence [®] groups Manipulation with lists of Auto Sequences [®] . Refer to chapter <i>4.9 Auto Sequence[®]</i> groups for more information.
User accounts	User accounts Users settings. Refer to chapter <i>4.6.6 User accounts</i> for more information.
Profiles	Profiles Selection of available instrument profiles.
े Settings	Settings Setting of different system parameters, including Ethernet settings.
Devices	Devices Selection of external devices. Refer to chapter <i>4.6.9 Devices</i> for more information.
Change password	Change password Changing password for enabling HV tests.
후 소 Initial Settings	Initial Settings Factory settings.



About

Instrument info.

4.6.1 Language

In this menu the language of the instrument can be set.



Figure 4.3: Select language menu

4.6.2 Date and time

In this menu date and time of the instrument can be set.

-	ⓑ Date	e/Time			02:12
	1	Dec	2014	10	32
	^	^	^	^	^
	\sim	\sim	\sim	\sim	\sim
		Set		Cancel	

Figure 4.4: Setting data and time menu

4.6.3 Profiles

Refer to Chapter 4.7 Instrument profiles for more information.

4.6.4 Workspace Manager

Refer to Chapter 4.8 Workspace Manager for more information.

4.6.5 Auto Sequence[®] groups

Refer to Chapter 4.9 Auto Sequence® groups for more information.

4.6.6 User accounts

In this menu user accounts can be managed:

- Setting if signing in to work with the instrument is required or not.
- Adding and deleting new users, setting their user names and passwords.
- The demand to sign in can prevent from unauthorized persons to work with the instrument.

If a user account is set and the user is signed in, the user's name will be stored in memory for each measurement.

The user accounts can be managed by the administrator. User account pasword consists of an up to 4 digit number. Individual users can change their passwords.

The administrator password consists of an up to 15 characters. Factory set administrator password is ADMIN. If the password is forgotten the second administrator password can be used. This password always unlocks the Account manager and is delivered with the instrument.

4.6.6.1 Signing in

By selecting User Accounts icon in Settings menu, Sign in menu appear on the screen. Same screen appear when instrument is switched on, if Sign in is set to required, see Chapter *4.6.6.3 Managing accounts* for details.




Figure 4.5: Sign in menu

Options

User signing in: Last signed-in Last signed in user is highlighted and displayed in the first row. Another user can be selected from the User accounts list. User accounts PETER GEORG BOJAN Enters User password entry screen. Enter the User password through the on-screen numerical 12:29 keyboard and confirm Password User profile screen is opened as presented on Figure 4.6. 1234 1 2 3 5 6 7 8 9 0

Administrator signing in:



Enters Account manager password entry screen.

12:30	Enter the Administrator password through on-screen keyboard and confirm
Password ADMIN	Account manager screen is opened as presented on <i>Figure</i> 4.7.
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	

4.6.6.2 Changing user password, signing out

After user completed Sign in procedure, User profile menu screen is presented. Same screen is presented if signed in user selects User accounts from General Settings menu.

🗅 User profile)	12:47
Username	GEORG	<
		8

Figure 4.6: User profile menu

Jptions		
Username	GEORG	Signed in user is displayed and highlighted on the top of the screen.
<		Sign out current user. Sign in screen appear, see Chapter <i>4.6.6.1 Signing in</i> for details.
8		Enters Account manager password entry screen, see Chapter 4.6.6.1 Signing in.
		Change User password. Numerical user password entry keyboard appear on the screen.
Password 1234 1 4 7	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	First step: enter current user password and confirm entry.

S User pr	ofile Err Incorrect p	password	08:13 	Wrong entry is reported by message. Confirm message, clear wrong password and repeat first step.
New passwor 4321	d 1 2 4 5 7 8 ← 0	6		Second step: enter new user password and confirm entry. Password change is confirmed with short message appearance.

4.6.6.3 Managing accounts

To access Account manager menu, Administrator should be signed in, see Chapter *4.6.6.1 Signing in* for details. Administrator can set sign in requirement, change Administrator password and edit user accounts. Appearance of Account manager screen depends on previous settings, see *Figure 4.7* below.




Figure 4.7: Account manager menu

Options

Sign in required NO Vesr sign in is not required. Sign in required YES Presented setting requires sign in, when instrument is s on. Sign in could also be set to required on every restar instrument. Image: Change Administrator password. Alphanumerical keyboard appears on the screen. Image: Change Administrator password. Alphanumerical keyboard appears on the screen. Image: Change Administrator password. Alphanumerical keyboard appears on the screen. Image: Change Administrator password. Alphanumerical keyboard appears on the screen. Image: Change Administrator password. Monumerical keyboard appears on the screen. Image: Change Administrator password. Monumerical keyboard appears on the screen. Image: Change Administrator password and content of the street of	of
Presented setting requires sign in, when instrument is s on. Sign in could also be set to required on every restar instrument. Image: Structure instrument instrument instrument. Image: Structure instrument instrument. Image: Structure instrument instrument. Image: Structure instrument instrument. Image: Structure instrument instrument instrument. Image: Structure instrument instrument instrument. Image: Structure instrument instrument instrument instrument instrument. Image: Structure instrument instrument instrument instrument instrument instrument instrument. Image: Structure instrument instrument. Image: Structure instrument instrum	of
Alphanumerical keyboard appears on the screen.	firm
ADMIN Q X X X X X C C C C C C C C C C C C C	firm
Sign in required Fror	
Every reboot	clear
New password Admin01 1 2 3 4 5 6 7 8 9 0 Second step: enter new Administrator password and co entry. Password change is confirmed with short message appearance. Account manager screen appear again. Administrator co continue to manage accounts or returns to Settings and menu.	an
Edit account icon. Enter Edit accounts screen, presented on <i>Figure 4.8</i> . For details see chapter <i>4.6.6.4 Edit user accounts</i> .	r

4.6.6.4 Edit user accounts

Administrator can add new user and set his password, change user existing password, delete user account and delete all user accounts.

Edit accounts screen is accessed by selecting Edit account icon from Account manager options screen, see Chapter 4.6.6.3 Managing accounts.

🖆 Edit accounts	10:53	🖆 Edit accounts	10:54
User accounts	+	User accounts	
PETER	×	PETER	×
GEORG		GEORG	
BOJAN		BOJAN	

Figure 4.8: Edit accounts screen – user list on the left, user selected on the right

User accounts	selected:
Options	
+	Add New user account. Add New menu appear on the screen.
Edit accounts 10:56 User account Add New PETER GEORG Password Add Canoel I	 Add New selection options: Username opens onscreen alphanumerical keyboard for new user name entry Password opens onscreen numerical keyboard for new user password entry Add stores new user to User account list. Cancel interrupts procedure
Edit accounts 13:51 User accounts PET Error Empty password not allowed BOJ. OK OK 111	New user account password must be entered; if not, warning message appears on the screen.
×	Delete all user accounts. Warning message appears on the screen.

Edit accounts 13:30 User accounts + P Warning! Are you sure you want to delete all accounts? * B YES NO	 Warning message selection options: YES: confirmation of deletion, all user accounts will be deleted NO: interrupts procedure and return to Edit accounts menu
Jser selected (user is highlighted PETER Dptions):
	Set password For selected user, password is set, numerical keyboard appears on the screen.
$ \begin{array}{c} $	Enter user password and confirm entry. Old user password is automatically overwritten without warning or confirmation.
×	Delete selected user account. Warning message appears on the screen.
Edit accounts 14:47 User accounts Warning! Are you sure you want to delete this account? B YES NO 111	 Warning message selection options: YES: confirmation of deletion, selected user account will be deleted NO: interrupts procedure and return to Edit accounts menu

4.6.7 Change password for HV functions

In this menu the password to enable starting of HV functions can be set, changed or disabled.




Figure 4.9: Change password menu

Notes:

- Default password is 0000.
- An empty entry disables the password.
- If password is lost, entry 4648 resets password to default.

4.6.8 Settings

In this menu different general parameters can be set.



Figure 4.10: Settings menu

Setting options:

Option	Description
Touch screen	ON – touch screen is active. OFF – touch screen is deactivated.
Keys & touch sound	ON – sound is active. OFF – sound is deactivated.
Test mode	Standard – Visual and Functional inspection status fields should be set manually. Expert – All Visual and Functional inspection status fields are filled automatically with PASS status.
Auto Seq. flow	 Ends if fail – Auto Sequence will end after first fail status of measurement / inspection is detected. Proceeding tests will be skipped. Proceeds if fail – Auto Sequence will proceed even if fail status of measurement / inspection is detected.

Ethernet setting options:

	Available selection	Description
Obtain an IP	[AUTOMATICALLY, MANUAL]	When the manual mode is chosen, the user must provide the correct network settings. Otherwise the instrument is automatically assigned an IP address fron the local network using the DHCP protocol.
IP address	XXX.XXX.XXX.XXX	Displays the instrument's IP address. In manual mode, the user should enter the correct value.
Port number	0 – 65535	Selects the port number on which the instrument listens for incoming connections. The instrument communicates using UDP/IP protocol. Max. UDP packe length is 1024 bytes.
Subnet mask	XXX.XXX.XXX.XXX	In manual mode, the user should enter the correct value.
Default gateway	XXX.XXX.XXX.XXX	In manual mode, depending on the network topology, the use can enter the correct value or leave it as it is, if not needed.
Preferred DNS server	XXX.XXX.XXX.XXX	In manual mode, depending on the network topology, the use can enter the correct value or leave it as it is, if not needed.
Alternate DNS server	XXX.XXX.XXX.XXX	In manual mode, depending on the network topology, the use can enter the correct value or leave it as it is, if not needed.
Host name	CA6165_XXXXXXXX	Displays the instrument's unique name on the local network. The host name consists of the instrument's name and its serial number.
MAC address	XX:XX:XX:XX:XX:XX	Displays the instrument's MAC address. User can change the address in case of another device on the

4.6.9 Devices

Devices			11:50	Devices			02:49
Writting device	1	Printer ZD410	>	Auto save		On print	>
Port	`	Bluetooth	>	Tag format	<	generic	
Bluetooth device name		PRN BT DONGLE		Туре	<	Socket CHS 7 2D	>
Bluetooth dongle		Initialize		Port		Bluetooth	
Print labels		50mm × 25.5mm		Bluetooth device nam	ne		

In this menu operation with external devices is configured.

Figure 4.11: Device settings menu

Writing devices	
Туре	Sets appropriate writing device (Serial printer, Bluetooth printer, RFID writer).
Port	Sets/views communication port of selected writing device.
Bluetooth device name	Goes to menu for pairing with selected Bluetooth device.
Bluetooth dongle	Initializes Bluetooth Dongle.
Print labels	Selects label form size. See Appendix C - Print labels and write / read RFID / NFC tags for details.
Printed date	Selects date printed on label text area, Options: [Test date, Retest date]. See Appendix C - Print labels and write / read RFID / NFC tags for details.
Auto save	Sets simultaneous saving of finished Auto Sequence when label is printed or RFID / NFC tag is written. Options: [On print, On write, OFF] See chapter <i>7.2.3 Auto Sequence</i> ® <i>result screen</i> for details.
Tag format	Sets PAT tag / label format or generic tag / label format. See Appendix C - Print labels and write / read RFID / NFC tags for details.
Reading devices	
Туре	Sets appropriate reading device (QR or barcode scanner, RFID reader, android device via an application).
Port	Sets/views communication port of selected reading device.
Bluetooth device name	Goes to menu for pairing with selected Bluetooth device.

4.6.10 Initial Settings

In this menu internal Bluetooth module can be initialized and the instrument settings, measurement parameters and limits can be set to initial (factory) values.

Initial Settings	13:20
– Bluetooth module will be – Instrument settings, mea: limits will reset to default v – Memory data will stay int:	surement parameters and alues.
ок	Cancel

Figure 4.12: Initial settings menu

Warning!

Following customized settings will be lost when setting the instruments to initial settings:

- Measurement limits and parameters
 Global parameters and System settings in General settings menu

Note:

Following customized settings will stay: Profile settings

- Data in memory
- Password for HV functions

4.6.11 About

In this menu instrument data (name, serial number, version and date of calibration) can be viewed.

🗅 About	09:39	
Name	C.A 6165 APPLIANCE MULTITESTER	
S/N	12345678	
FW version	1.59.5.9007 - ANAF	
HW version	4.0	
Date of calibration 01.Jan.2018		
Chauvin Arnoux, www.chauvin-arnoux.com		

Figure 4.13: Instrument info screen

4.7 Instrument profiles

In this menu the instrument profile can be selected from the available ones.




Figure 4.14: Instrument profile menu


The instrument uses different specific system and measuring settings in regard to the scope of work or country it is used. These specific settings are stored in instrument profiles.

By default each instrument has at least one profile activated. Proper licence keys must be obtained to add more profiles to the instruments.

If different profiles are available they can be selected in this menu.

Refer to Appendix B - Profile Notes for more information about functions specified by profiles.

Options



4.8 Workspace Manager

The Workspace Manager is intended to manage with different Workspaces and Exports stored on the microSD card.

4.8.1 Workspaces and Exports

The works with C.A 6165 can be organized with help of Workspaces and Exports. Exports and Workspaces contain all relevant data (measurements, parameters, limits, structure objects) of an individual work.




Figure 4.15: Organization of Workspaces and Exports on microSD card

Workspaces are stored on microSD card on directory WORKSPACES, while Exports are stored on directory EXPORTS. Exports are suitable for making backups of important works or can be used for storage of works if the removable microSD card is used as a mass storage device. To work on the instrument an Export should be imported first from the list of Exports and converted to a Workspace. To be stored as Export data a Workspace should be exported first from the list of Workspaces and converted to an Export.

4.8.2 Workspace Manager main menu

In Workspace manager Workspaces and Exports are displayed in two separated lists.

🗢 Workspace Manager	00:02	Subscription Service Manager	06:19
WORKSPACES:	∎⇔●	EXPORTS:	∎⇔●
Grand hotel Union	+	Grand hotel Union	
Hotel Cubo		Hotel Cubo	
Hotel Slon		Hotel Slon	
Grand hotel Toplice		Grand hotel Toplice	

Figure 4.16: Workspace manager main menu

Options

WORKSPACES:	List of Workspaces.
■⇔●	Displays a list of Exports.
+	Adds a new Workspace. Refer to chapter <i>4.8.2.3 Adding a new Workspace</i> for more information.
EXPORTS:	List of Exports.
	Displays a list of Workspaces.

4.8.2.1 Operations with Workspaces

Only one Workspace can be opened in the instrument at the same time. The Workspace selected in the Workspace Manager will be opened in the Memory Organizer.



Figure 4.17: Workspaces menu

Options

•	
•	Marks the opened Workspace in Memory Organizer. Opens the selected Workspace in Memory Organizer.
	Refer to chapters 5 <i>Memory Organizer</i> and <i>4.8.2.4 Opening a Workspace</i> for more information.
×	Deletes the selected Workspace. Refer to chapter <i>4.8.2.5 Deleting a Workspace / Export</i> for more information.
+	Adds a new Workspace. Refer to chapter <i>4.8.2.3 Adding a new Workspace</i> for more information.
▶</th <th>Exports a Workspace to an Export Refer to chapter <i>4.8.2.7 Exporting a Workspace</i> for more information.</th>	Exports a Workspace to an Export Refer to chapter <i>4.8.2.7 Exporting a Workspace</i> for more information.

4.8.2.2 Operations with Exports



Figure 4.18: Workspace manager Exports menu

Options



4.8.2.3 Adding a new Workspace



New workspaces can be added from the Workspace manager screen.

Enters option for adding a new Workspace.

Keypad for entering name of a new Workspace is displayed after selecting New.



After confirmation a new Workspace is added to the list of workspaces.

4.8.2.4 Opening a Workspace


1	Workspace Manager WORKSPACES: Grand hotel Union Hotel Cubo	08:12 • *	Workspace can be selected from a list in Workspace manager screen.
2	•		Opens a Workspace in Workspace manager.
	Workspace Manager WORKSPACES: Grand hotel Union Hotel Cubo	08:12 • * *	The opened Workspace is marked with a blue dot. The previously opened Workspace will close automatically.

4.8.2.5 Deleting a Workspace / Export



Workspace / Export to be deleted should be selected from the list of Workspaces / Exports.


Enters option for deleting a Workspace / Export.



4.8.2.6 Importing a Workspace

Workspace Manager EXPORTS: Grand hotel Union Hotel Cubo	06:19 Select an Export file to be imported from Workspace manager Export list.
Hotel Sion Grand hotel Toplice	444
Workspace Manager	Enters option Import.
EXPORTS: Grand hot Import to workspace? Hotel Cub Grand hotel Toplice Hotel Slor YES NO Grand hotel Toplice	Before the import of the selected Export file the user is asked for confirmation.
Image: Workspace Manager WORKSPACES: Grand hotel Union Hotel Cubo Hotel Slon Grand hotel Toplice	 00:02 The imported Export file is added to the list of Workspaces. Note: If a Workspace with the same name already exists the name of the imported Workspace will be changed (name_001, name_002, name_003,).

4.8.2.7 Exporting a Workspace



4.9 Auto Sequence® groups

The Auto Sequences[®] in C.A 6165 are organized in Auto Sequence[®] groups stored in folders on the microSD memory card. Folders are located in *Root_MOS_VAT* on the microSD card.




Figure 4.19: Organization of Auto Sequence® groups on microSD card

Each group contain similar Auto Sequences[®]. The Auto Sequence[®] groups menu is intended to manage with different Auto Sequences[®].

4.9.1 Auto Sequence[®] groups menu

Auto Sequence[®] groups menu can be accessed from General settings menu followed by selection of Auto Sequence[®] groups menu.

Another option to access it is from Main Auto Sequences[®] menu, see chapter 7.1 Selection of Auto Sequences[®]. In this menu lists of Auto Sequence[®] groups are displayed. Only one group can be active in the instrument at the same time. The group selected from the Auto Sequence[®] groups menu will be opened whenever Auto Sequence[®] menu is selected from the instrument Main menu, see chapter 4.5 Instrument main menu.

🛨 Auto Sequence® groups	14:04
CLASS I	•
CLASS II	×
CLASS III	
	444


Figure 4.20: Auto Sequence® groups menu

4.9.1.1 Operations in Auto Sequence[®] groups menu

Options

•	Opens the selected group of Auto Sequences [®] . Previously selected group of Auto Sequences [®] will be closed automatically. Refer to chapter <i>4.9.1.2 Selecting a group of Auto Sequences</i> ® for more information.
×	Deletes the selected list of Auto Sequences [®] . Refer to chapter <i>4.9.1.3</i> Deleting a group of Auto Sequences® for more information.

4.9.1.2 Selecting a group of Auto Sequences[®]



4.9.1.3 Deleting a group of Auto Sequences®

1	Auto Sequence® groups CLASS I CLASS II CLASS II CLASS III	14:05	A group of Auto Sequences [®] to be deleted should be selected first from the list of Auto Sequence [®] groups.
2	×		Enters option for deleting the selected group.
	Auto Sequence® groups CLASS I CLA CLA CLA Are you sure you want to remove this Auto Sequence® group? YES N0	14:06	Before deleting the selected group of Auto Sequences [®] , the user is asked for confirmation.
3	 Auto Sequence® groups CLASS I CLASS III 	14:06	A group of Auto Sequences [®] is deleted. Note: Selected Auto Sequences [®] group (marked with blue dot) cannot be deleted, warning message appear on the screen.

5 Memory Organizer

Memory Organizer is a tool for storing and working with test data.

5.1 Memory Organizer menu

The data is organized in a tree structure with Structure objects and Measurements. C.A 6165 has a fixed three level structure. The hierarchy of Structure objects in the tree is shown on *Figure 5.1*.




Figure 5.1: Tree structure and its hierarchy




Figure 5.2: Example of a Tree menu

5.1.1 Measurement statuses


Each measurement has:

- a status (Pass or Fail or no status)
- a name
- results
- limits and parameters

A measurement can be a Single test or an Auto Sequence® test. Statuses of single tests:

passed finished single test with test results
failed finished single test with test results
finished single test with test results and no status
empty single test without test results

Overall statuses of Auto Sequence® tests:



5.1.2 Structure Objects

Each Structure object has:

- an icon
- a name
- parameters
- Optionally they can have:

an indication of the status of the measurements under the Structure object

a comment or a file attached

Structure objects supported in C.A 6165 are described in Appendix A - Structure objects in C.A 6165.



Figure 5.3: Structure object in tree menu

5.1.2.1 Measurement status indication under the Structure object

Overall status of measurements under each structure element / sub-element can be seen without spreading tree menu. This feature is useful for quick evaluation of test status and as guidance for measurements.

Options





Figure 5.4: Example of status - No measurement result(s)



One or more measurement result(s) under selected structure object has failed. Not all measurements under selected structure object have been made yet.



Figure 5.5: Example of status - Measurement not completed with fail result(s)




Note:

There is no status indication if all measurement results under each structure element / sub-element have passed or if there is an empty structure element / sub-element (without measurements).


5.1.3 Selecting an active Workspace in Memory Organizer

Memory Organizer and Workspace Manager are interconnected so an active Workspace can be selected also in the Memory Organizer menu.



5.1.4 Adding Nodes in Memory Organizer

Structural Elements (Nodes) are used to ease organization of data in the Memory Organizer. One Node is a must; others are optional and can be created or deleted freely.



5.1.5 Operations in Tree menu

In the Memory organizer different actions can be taken with help of the control panel at the right side of the display. Possible actions depend on the selected element in the organizer.

Operations on measurements (finished or empty measurements) 5.1.5.1

The measurement must be selected first. Operation options can be selected from the menu on the right side of the screen. Menu options are adapted to measurement status, empty, finished, finished and saved, as presented on Figure 5.7.

🗂 Memory Organizer	06:52	🗂 Memory Organizer	06:53
🚠 Iron sn 23452345	iğ	🔜 Iron sn 23452345	
🖃 р Sample project	3	🖃 р Sample project	
SAT receiver SN876543		SAT receiver SN876543	
🔵 R ISO		🛑 R ISO	
Subleakage	4	🔵 Subleakage	+
O Differential Leakage	•••	O Differential Leakage	444

Figure 5.7: A measurement is selected in the Tree menu

Options

iq	Views results of measurement. The instrument goes to the measurement memory screen. Refer to chapters <i>6.1.1.5 Single test memory screen</i> and <i>7.2.4 Auto Sequence[®] memory</i> screen for more information.
	Starts a new measurement. The instrument goes to the measurement start screen. Refer to chapters 6.1.1.1 Single test start screen and 7.2.1 Auto Sequence [®] view menu for more information.
	Saves a measurement. Saving of measurement on a position after the selected (empty or finished) measurement.
	Clones the measurement. The selected measurement can be copied as an empty measurement under the same Structure object. Refer to chapter <i>5.1.5.7 Clone a measurement</i> for more information.
	Copies & Paste a measurement. The selected measurement can be copied and pasted as an empty measurement to any location in structure tree. Multiple "Paste" is allowed. Refer to chapter <i>5.1.5.10 Copy & Paste a</i> <i>measurement</i> for more information.
•	Adds a new measurement. The instrument goes to the Menu for adding measurements. Refer to chapter <i>5.1.5.5 Add a new measurement</i> for more information.
	Views and edit comments. The instrument displays comment attached to the selected measurement or opens keypad for entering a new comment.
€ x	Deletes a measurement. Selected Measurement can be deleted. User is asked for confirmation before the deleting. Refer to chapter <i>5.1.5.12 Delete a measurement</i> for more information.


5.1.5.2 Operations on Structure objects

The structure object must be selected first.

Memory Organizer	15:50	▲ Memory Organizer	06:44
🗉 🚬 Node		🗉 🚬 Node	
🔁 Iron SN 12341234		🔁 Iron SN 12341234	
🔁 Iron sn 23452345		🔁 Iron sn 23452345	
🖃 р Sample project		🖃 👂 Sample project	R
💿 🔁 SAT receiver SN876543	Ø	SAT receiver SN876543	
😑 R ISO		🖭 📠 TV receiver SN 34567	

Figure 5.8: A structure object is selected in the tree menu

Starts a new measurement. First type of measurement (Single test or Auto Sequence [®]) should be selected. After proper type is selected, the instrument goes to single test or Auto Sequence [®] selection screen. Refer to chapters <i>6.1 Selection of single tests</i> and <i>7.1</i> <i>Selection of Auto Sequences® for more information.</i>
Saves a measurement. Saving of measurement under the selected Structure object.
View / edit parameters and attachments. Parameters and attachments of the Structure object can be viewed or edited. Refer to chapter 5.1.5.3 View / Edit parameters and attachments of a Structure object for more information.
Adds a new measurement. The instrument goes to the Menu for adding measurement into structure. Refer to chapter <i>5.1.5.5</i> <i>Add a new measurement</i> for more information.
Adds a new Structure object. A new Structure object can be added. Refer to chapter <i>5.1.5.4 Add a new Structure Object</i> for more information.
Attachments. Name and link of attachment is displayed.
Clones a Structure object. Selected Structure object can be copied to same level in structure tree (clone). Refer to chapter <i>5.1.5.6 Clone a Structure object</i> for more information.
Copies & Paste a Structure object. Selected Structure object can be copied and pasted to any allowed location in structure tree. Multiple "Paste" is allowed. Refer to chapter <i>5.1.5.8 Copy & Paste a Structure object</i> for more information.
Views and edit comments. The instrument displays comment attached to the selected Structure object or opens keypad for entering a new comment.
-



5.1.5.3 View / Edit parameters and attachments of a Structure object

The parameters and their content are displayed in this menu. To edit the selected parameter tap on it or press Enter key to enter menu for editing parameters.

🗅 Memory Orga	nizer / Parameters 11:37
🔚 TV receiver Sl	N 34567
Appliance ID	TV receiver SN 34567
Inventary No.	34567-TV
Name	Television
Location (Room)	Living room
	Appliance ID Inventary No. Name

Figure 5.9: Example of View / Edit parameters menu

Name 08:10 Oven / Hotplate PC / Monitor Portable Heating Power Tools Printer / Scanner	In menu for editing parameters the parameter's value can be selected from a dropdown list or entered via keypad. Refer to chapter 4 <i>Instrument operation</i> for more information about keypad operation.
S Memory Organizer / Attachments 11:51	Attachments
TV receiver SN 34567 docs/P3212eba5a5b240fc98948dca9144272a_picture.jpg	The name of attachment can be seen. Operation with attachments is not supported in the instrument.
0 doos/Po78da9ob17484ao3806a999a43f7o2dd_q.png	

5.1.5.4 Add a new Structure Object

This menu is intended to add new structure objects in the tree menu. A new structure object can be selected and then added in the tree menu.


		Add	New	
Ad	dd Structure	element:		
		name:		
		Project		
		parameters:		
		Add	Cancel	
	F	igure 5.10: Add a new	Structure Object menu	


element: Project Element type 12:03 Project Location Appliance_FD Appliance Node	The type of Structure object to be added can be selected from dropdown menu. Only structure objects that can be used in the same level or next sublevel are offered.
name: Project $\begin{array}{c} \bullet \\ \hline \\$	The name of the Structure object can be edited.
parameters: • Memory Organizer / Parameters • Project Name (designation) of project Description (of project)	Parameters of the Structure object can be edited.

ン INPUT TEXT 08:56 Description (of project)	
1 2 3 4 5 6 7 8 9 0 Q W E R T Y U I 0 P A S D F G H J K L shift Z X C V B N M ← → eng ;	
Add	Adds the selected structure object and its parameters in the tree menu.
Cancel	Returns to the tree menu without changes.

5.1.5.5 Add a new measurement


In this menu new empty measurements can be set and then added in the structure tree. The type of measurement, measurement function and its parameters are first selected and then added under the selected Structure object.






5.1.5.6 Clone a Structure object

In this menu selected structure object can be copied (cloned) to same level in the structure tree. Cloned structure object have same name as original.



Procedure and options 🗂 Memory Organizer 08:58 Select the structure object to be cloned. \bigcirc Node Attachments 🚠 Iron SN 12341234 Glone 🔜 Iron sn 23452345 Copy ple project Remove V receiver SN 34567 Rename Select Clone option from control panel. 2 Clone The Clone Structure object menu is displayed. Sub-elements of 3 Include structure parameters the selected structure object can be marked or un-marked for cloning. Include structure attachments Refer to chapter 5.1.5.9 Cloning and Pasting sub-elements of selected structure object for more information. Include sub structures Include sub measurements Clone Cancel Selected structure object is copied (cloned) to same level in the 4 Clone structure tree. а



5.1.5.7 Clone a measurement


By using this function a selected empty or finished measurement can be copied (cloned) as an empty measurement to the same level in the structure tree.

Procedure and options

1	Memory Organizer Mode Node Project Appliance_FD R ISO Appliance_FD	03:32	Select the measurement to be cloned.
2	Clone		Select Clone option from control panel.
3	Memory Organizer Memory Organizer Rode Project Appliance_FD R ISO Appliance_FD	03:32	The new empty measurement is displayed.

5.1.5.8 Copy & Paste a Structure object

In this menu selected Structure object can be copied and pasted to any allowed location in the structure tree.



2	Сору	Select Copy option from control panel.
3	Memory Organizer 09:18 Node Clone Iron SN 12341234 Copy Iron SN 23452345 Paste Sample project Iv receiver SN 34567 TV receiver SN 34567 Remove Sample project Rename	Select location where structure element should be copied.
4	Paste	Select Paste option from control panel.
5	Include structure parameters Include structure attachments Include sub structures Include sub measurements Paste Cancel	The Paste structure object menu is displayed. Before copying it can be set which sub-elements of the selected structure object will be copied too. For more details see chapter 5.1.5.9 Cloning and Pasting sub-elements of selected structure object.
6 a	Paste	The selected structure object and elements are copied (pasted) to selected position in the tree structure.
6 b	Cancel	Returns to the tree menu without changes.
Ø	Memory Organizer 09:19 Node Iron SN 12341234 Iron SN 12341234 Image: Constraint of the second se	The new structure object is displayed. Note: The Paste command can be executed one or more times.

5.1.5.9 Cloning and Pasting sub-elements of selected structure object

When structure object is selected to be cloned, or copied & pasted, additional selection of its sub-elements is needed. The following options are available:


Options

Include structure parameters	Parameters of selected structure object will be copied too.
	-

Include structure attachments	Attachments of selected structure object will be copied too.
Include sub structures	Structure objects in sub-levels of selected structure object will be copied too.
Include sub measurements	Measurements in selected structure object and sub-levels will be copied too.

5.1.5.10 Copy & Paste a measurement

In this menu selected measurement can be copied to any allowed location in the structure tree.



5.1.5.11 Delete a Structure object


Procedure

In this menu selected Structure object can be deleted.

loccu		
1	Memory Organizer 09:16 Node Image: Attachments Image: Ima	Select the structure object to be deleted.
2	Delete	Select Delete option from control panel.
3	Memory Organizer Memory Organizer Are you sure you want to delete? TV recever SN 34567 YES NO Recever	A confirmation window will appear.
(∄a	YES	Selected structure object and its sub-elements are deleted.
4 b	NO	Returns to the tree menu without changes.

5.1.5.12 Delete a measurement

In this menu selected measurement can be deleted.




3	 Project Are you sure you want to delete? R ISO YES NO R ISO 	11:27 ••• ••• ••• •••	A confirmation window will appear.
4a	YES		Selected measurement is deleted.
₫b	NO		Returns to the tree menu without changes.

5.1.5.13 Rename a Structure object

In this menu selected Structure object can be renamed.

1		09:16 Attachments	Select the structure object to be renamed.
	 Iron SN 12341234 Iron sn 23452345 Sample project TV receiver SN 34567 Sample project 	Clone Copy Remove Rename	
2	Rename		Select Rename option from control panel.
3		08:47 08:47 0 0 0 0 0 0 0 0 0 0 0 0 0	Virtual keypad will appear on screen. Enter new text and confirm.


5.1.5.14 Recall and Retest selected measurement



6		Select Run in Control panel to retest the measurement.
\bigcirc	R iso 14:32 Riso 1999.9 Riso Γ Um 263 V Type Riso Uso 250 V Duration 5 s L Limit(Riso) 0.30 MΩ H Limit(Riso) 0.30 MΩ	Results / sub-results after re-run of recalled measurement.
8		Select Save results in Control panel.
	Memory Organizer 14:33 Workspace002 Image: Constraint of the second seco	Retested measurement is saved under same structure object as original one. Refreshed memory structure with the new performed measurement is displayed.

5.1.6 Searching in Memory Organizer

In Memory organizer it is possible to search for different structure objects and parameters.



3	Search 15:40 All Q Name Q Status Q Equipment Q Equipment ID Pass Test date From Retest date From	The parameters that can be searched for are displayed in the Search setup menu. Name and status are referred to all structure objects. If searching by status, instrument will display all structure objects that include one or more measurements with searched status. Equipment ID, Test date, Retest date refer only to the following structure objects: Appliance, Appliance FD, Machine and Switchgear.
3a	Name Equipment ID 11:31 Name IRON $\frac{1}{2}$ $\frac{3}{2}$ $\frac{4}{8}$ $\frac{5}{7}$ $\frac{6}{7}$ $\frac{3}{10}$ $\frac{9}{7}$ $\frac{1}{10}$ $\frac{9}{7}$ $\frac{1}{10}$ $\frac{9}{7}$ $\frac{1}{10}$ $\frac{1}{10}$ $\frac{9}{7}$ $\frac{1}{10}$ \frac	The search can be narrowed by entering a text in the Name and Equipment ID fields. Strings can be entered using the on-screen keyboard. Note: The Search function on Equipment ID is case sensitive.
3b	A S D F G H J K L shift Z X C V B N M H 1 12# . . eng L . eng Status Pass Status Fail Empty No status	The search can be narrowed on base of statuses.
3c	Test date Retest date 16 Dec 2015 A A A V V V Set Cancel	The search can be narrowed on base of test dates / retest dates (from / to).
3d	X Clear filters	Clears all filters. Sets filters to default value.
4	Search	Searches through the Memory Organizer for objects according to the set filters. The results are shown in the Search results screen presented on <i>Figure 5.13</i> and <i>Figure 5.14</i> .




Figure 5.13: Search results screen – Page view

Options

>	Next page.
<	Previous page.

Note:

Search result page consist of up to 50 results.

Search results	17:01
Page 1/2	'E = >
□ • 12015002	
a 12015003	
🚬 ₀ 12015110	R
🚬 ₀ 12015112	
🚬 o 12015113	

Figure 5.14: Search results screen with structure object selected

Options

	Goes to selected location in Memory Organizer.
	View / edit parameters and attachments. Parameters and attachments of the Structure object can be viewed or edited. Refer to <i>Chapter 5.1.5.3 View / Edit parameters and attachments of a Structure object</i> for more information.
Ø	Attachments. Name and link of attachment is displayed.
R.	Renames the selected Structure object. Refer to <i>Chapter 5.1.5.13 Rename a Structure object</i> for more information.



Views comment.


The instrument displays comment attached to the selected Structure object.

6.1 Selection of single tests


Single tests can be selected in the Main single test menu or in Memory Organizer's main and submenus. In Single test main menu there are four modes for selecting single tests.

Options

All	
	gle test can be selected from a list of all single tests. single tests are always displayed in the same ault) order.
Last	used
Single Tests 10:15 Continuity LEAK ISUB Sub-leakage ISO Riso	9 made different single tests are displayed.
Grou	ıps
Single Tests 09:06 VISUAL ISO LEAK DISCH CONT POWER	single tests are divided into groups of similar tests.
HV FUNCT.	







For the selected group a submenu with all single tests that belongs to the selected group is displayed.

Cross selector

This selection mode is the fastest way for working with the keypad.

Groups of single tests are organized in a row.

For the selected group all single tests are displayed and accessible with up/down keys.

6.1.1 Single test screens

In the Single test screens measuring results, sub-results, limits and parameters of the measurement are displayed. In addition on-line statuses, warnings and other information are displayed.





Figure 6.1: Single test screen organisation


6.1.1.1 Single test start screen

Single test screen can be opened from Memory organizer or from Single test main menu.





Options



6.1.1.2 Setting parameters and limits of single tests

🛨 Paramete	ers & Limi	ts	08:33	t3		01:48
Duration		Off	>		1 s	
Output		40 V			2 s	
H Limit(Isub)	<	0.25 mA	>	t3	3 s	
L Limit(Isub)	<	1.00 mA	>		4 s	
				(5 s	



Options	
Off	Selects parameter (white) or limit (red).
40 V	
0.25 mA	
1.00 mA	
Off	Selects value of parameter or limit. In case of many (multiple pages of) parameters or limits:
2 s	- The scroll bar on the right side of screen can be used
3 s	- With right / left keys it can be jumped page up / page down
5 s	
10 s	
1 H Limit 08:09	Some of limits can be user defined.
6 Ω	Selects Custom and tap on it.
7Ω H Limit	
8 Ω	
9 û	
Custom	
S 08:10	Numeric keyboard with metric prefixes will open.
H Limit [Ω]	Enters custom limit value and confirm entry.
59.87m	
<u>123</u> 456 k	
7 <u>8 9</u> M	

6.1.1.3 Single test screen during test




Figure 6.4: Single test screen (during measurement)

Options (during test)

	Stops the single test measurement.
	Proceeds to the next step of the measurement (if measurement consists of more steps).
Ţ	Aborts measurements.

6.1.1.4 Single test result screen





Figure 6.5: Single test result screen

Options (after measurement	is	finished)
----------------------------	----	-----------



- A new measurement was selected and started from a Structure object in the structure tree:
 - The measurement will be saved under the selected Structure object.

A new measurement was started from the Single test main menu:

Saving under the last selected Structure object will be offered by default. The user can <u>select another Structure object or create a new Structure object</u>. By pressing



_

the key in Memory organizer menu the measurement is saved under selected location.

An empty measurement was selected in structure tree and started:

- The result(s) will be added to the measurement. The measurement will change its status from 'empty' to 'finished'.

An already carried out measurement was selected in structure tree, viewed and then restarted:

- A new measurement will be saved under the selected Structure object.

	Adds comment to the measurement. The instrument opens keypad for entering a comment.		
?	Opens help screens. Refer to chapter 6.1.3 Help screens for more information.		
	Opens screen for changing parameters and limits. Refer to chapter <i>6.1.1.2 Setting parameters and limits of single</i> <i>tests</i> for more information.		
Duration H Limit(Idiff) L Limit(Idiff)	Off Off Off		

6.1.1.5 Single test memory screen




Figure 6.6: Single test memory screen

Options

C	Retest Enters screen with "empty" measurement.
	Opens menu for viewing parameters and limits.
	Refer to chapter 6.1.1.2 Setting parameters and limits of single tests for more information.



6.1.2 Single test (inspection) screens

Visual and Functional inspections can be treated as a special class of tests. Items to be visually or functionally checked are displayed. In addition on-line statuses and other information are displayed.




Figure 6.7: Inspection screen organisation

6.1.2.1 Single test (inspection) start screen






Figure 6.8: Inspection start screen

Options (inspection screen was opened in Memory organizer or from Single test main menu)



6.1.2.2 Single test (Inspection) screen during test





Options (during test)

Visual Machine IEC/EN 60204	Selects item
Protective_measures	
Size of conductors	
	Applies a pass status to the selected item or group of items.
×	Applies a fail status to the selected item or group of items.
	Clears status in selected item or group of items
•	Applies a checked status to the selected item or group of items.
n D	A status can be applied direct to the checkbox; successive tap toggle between statuses.
Р	Power is applied to the mains test socket to power up the tested equipment during a functional inspection. The instrument displays the Power measurement screen, refer to <i>Chapter 6.2.12 Power for details</i> .
	Stop the inspection. Enters result screen if all items are checked.
1	Goes to the result screen, if inspection test running. Goes to the previous menu, if inspection test was stopped before.

Rules for automatic applying of statuses:

> The parent item(s) can automatically get a status on base of statuses in child items.

- the fail status has highest priority. A fail status for any item will result in a fail status in all parent items and an overall fail result.
- if there is no fail status in child items the parent item will get a status only if all child items have a status.
- Pass status has priority over checked status.
- The child item(s) will automatically get a status on base of status in the parent item
 All child items will get the same status as applied to the parent item.

Note

 Inspections and even inspection items inside one inspection can have different status types. For example some basic inspections don't have the 'checked' status.

6.1.2.3 Single test (Inspection) result screen




Figure 6.10: Inspection result screen

Options (after inspection is finished)

	Starts a new inspection.
	 Saves the result. A new inspection was selected and started from a Structure object in the structure tree: The inspection will be saved under the selected Structure object. A new inspection was started from the Single test main menu: Saving under the last selected Structure object will be offered by default. The user can select another Structure object or create a new Structure object. By pressing the key in Memory organizer menu the inspection is saved under selected location. An empty inspection was selected in structure tree and started: The result(s) will be added to the inspection. The inspection will change its status from 'empty' to 'finished'. An already carried out inspection was selected in structure tree, viewed and then restarted: A new measurement will be saved under the selected Structure object.
?	Opens Help screen, see chapter 6.1.3 Help screens for more information.

6.1.2.4 Single test (inspection) memory screen





Figure 6.11: Inspection memory screen

Options	
C	Retest Starts inspection with cleared statuses.
iq	Enters view mode.

6.1.3 Help screens

Help screens contain diagrams for proper connection of the instrument.





Options

on

Goes to previous / next help screen.

6.2 Single test measurements

6.2.1 Visual inspections




Figure 6.13: Visual inspection menu




Figure 6.14: Visual inspection test circuit

Visual inspection procedure

- Select the appropriate Visual inspection.
- Start the inspection.
- Perform the visual inspection of the appliance / equipment.
- Apply appropriate ticker(s) to items of inspection.
- End inspection.
- Save results (optional).

Inspection	10:17	➡ Inspection		10:17
Visual Machine IEC/EN 60204	🖌 🕨	Visual Machine IEC/EN 60204	X	
Protective_measures	- 🖌 📄	Protective_measures	×	
Protection against direct contact		Protection against direct contact		
Protection against indirect contact		Protection against indirect contact		
Size of conductors	<mark>, </mark>	Size of conductors	×	?
Overcurrent protective devices	•••	Overcurrent protective devices		•••

Figure 6.15: Examples of Visual inspection results

Test circuit

6.2.2 Continuity




Figure 6.16: Continuity test menu

Test results / sub-results

R..... Resistance

 $\Delta U.....Voltage drop scaled to 10 A$

Test parameters

Output connections	Output [4-wire, P-PE]
Test current	I out [0.2 A, 4 A, 10 A, 25 A]
Duration	Duration [Off, 2 s 180 s]
ΔU test*	Enables ΔU test [On, Off]
Wire section*	Wire section for ΔU test [0.5 mm ² \geq 6mm ²]

Test limits

H Limit (R)	H limit [Off, 0.01 Ω 9 Ω, Custom]
L Limit (R)	L limit [Off, 0.01 Ω 9 Ω, Custom]
H Limit (ΔU)*	H limit [1.0 V 5.0 V]

* Applicable only at test current 10 A.

Test circuit




Figure 6.17: Measurement of continuity 4-wire




Figure 6.18: Measurement of Continuity P/S - PE

Continuity measurement procedure


- Select the **Continuity** function.
- Set test parameters / limits.
- Connect test leads to C1, P1, P2 and C2 terminals on the instrument (4 wire), or connect test lead to P/S terminal (2 wire measurement P/S – PE).
- Compensate test leads resistance (optional).
- Connect test leads to device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).

🗅 Continuity		15:13	🗅 Continuity		15:14
R 0.0)G		8.94	×	
	Ω		R O.JHΩ		
Output I out Duration	4 wire 0.2 A 2 s	?	Output 4 wire lout 0.2 A Duration 2 s		?
H Limit(R) L Limit(R)	1Ω Off	•••	H Limit(R) 1 Ω L Limit(R) Off		•••

Figure 6.19: Examples of Continuity measurement results

6.2.2.1 Compensation of test leads resistance

This chapter describes how to compensate the test leads resistance in **Continuity (Output = P/S - PE)** function. Compensation can be carried out to eliminate the influence of test leads resistance and the internal resistances of the instrument on the measured resistance.



Connection for compensating the resistance of test leads

Figure 6.20: Shorted test leads

Compensation of test leads resistance procedure

- Select the **Continuity** function. Parameter Output must be set to P/S PE.
- Connect test leads to the instrument and short the test leads together, see Figure 6.20.
- Touch the key to compensate leads resistance.
- Symbol is displayed if the compensation was carried out successfully.



Figure 6.21: Uncompensated and compensated result

Note:

The compensation of test leads is carried out with set test current (I out).

6.2.3 HV AC



Refer to chapter 1.1 Warnings and notes for more information regarding safe use of the instrument.




Figure 6.22: HV AC test menu

Test results / sub-results

I test current
U measured a.c. test voltage
Ir resistive portion of test current
Ic capacitive portion of test current

Test parameters

AC test voltage	U test [100 V 5000 V in steps of 10 V]
Duration	t end [Off, 1 s 120 s]

Test limits

High limit (I)	H limit [0.5 mA 100 mA]
Low limit (I)	L limit [Off, 0.5 mA 100 mA]

Test circuit




Figure 6.23: HV AC measurement

HV AC measurement procedure

- Select the HV AC function.
- Set test parameters / limits.
- Connect HV test leads to HV(~,+) and HV(~,-) terminals on the instrument.
- Connect HV test leads to device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.24: Examples of HV AC meaasurement results

Note:

•

First HV measurement after power on the instrument (if password protection is enabled) or first HV measurement after enabling or changing password require entering password for enabling HV test. Refer to chapter 4.6.7 Change password for HV functions for more information.

6.2.4 HV DC

IMPORTANT SAFETY NOTE

Refer to chapter 1.1 Warnings and notes for more information regarding safe use of the instrument.




Figure 6.25: HV DC test menu

Test results / sub-results

U..... measured test voltage I..... test current


Test parameters

DC test voltage	U test [500 V 6000 V in steps of 50 V]
Duration	t end [Off, 1 s 120 s]

Test limits

High limit (I)	H limit [0.05 mA 10.0 mA]
Low limit (I)	L limit [Off, 0.05 mA 10.0 mA]

Test circuit





HV DC measurement procedure

- Select the HV DC function.
- Set test parameters / limits.
- Connect HV test leads to HV(~,+) and HV(~,-) terminals on the instrument.
- Connect HV test leads to device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.27: Examples of HV DC measurement results

Note:

 First HV measurement after power on the instrument (if password protection is enabled) or first HV measurement after enabling or changing password require entering password for enabling HV test. Refer to chapter 4.6.7 Change password for HV functions for more information.

6.2.5 HV AC programmable

M IMPORTANT SAFETY NOTE

Refer to chapter 1.1 Warnings and notes for more information regarding safe use of the instrument.

In the HV AC programmable test the time dependency of high voltage can be set according to diagram on Figure 6.28.




Figure 6.28: Voltage / time diagram of the HV AC programmable test

🗂 HV AC programmable		09:52
i <u> </u>	mA	
U	_ v	
lr mA lc	mA	?
U start U test	500 V 1000 V	
t start t ramp t end	2 s 5 s 5 s	444

Figure 6.29: HV AC programmable test menu

Test results / sub-results

I test current
U measured test voltage
Ir resistive portion of test current
Ic capacitive portion of test current

Test parameters

Starting AC test voltage	U start [100 V 5000 V in steps of 10 V]
AC test voltage	U test [100 V 5000 V in steps of 10 V]
Duration of starting voltage	t start [1 s 120 s]
Duration of ramp	t ramp [2 s 60 s]
Duration of test voltage	t end [Off, 1 s 120 s]

Test limits

High limit (I)	H limit [0.5 mA 100 mA]
Low limit (I)	L limit [Off, 0.5 mA 100 mA]

Test circuit




Figure 6.30: HV AC programmable test

HV AC programmable test procedure

- Select the HV AC programmable function.
- Set test parameters / limits.
- Connect HV test leads to HV(~,+) and HV(~,-) terminals on the instrument.
- Connect HV test leads to device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.31: Examples of HV AC programmable test results

Note:

First HV measurement after power on the instrument (if password protection is enabled) or first HV measurement after enabling or changing password require entering password for enabling HV test. Refer to chapter *4.6.7 Change password for HV functions* for more information.

6.2.6 HV DC programmable

M IMPORTANT SAFETY NOTE

Refer to chapter 1.1 Warnings and notes for more information regarding safe use of the instrument.

In the HV DC programmable test the time dependency of high voltage can be set according to diagram on Figure 6.28.




Figure 6.32: HV DC programmable test menu

Test results / sub-results

U..... measured test voltage

I test current

Ic capacitive portion of test current

Ir resistive portion of test current

Test parameters

Starting DC test voltage	U start [500 V 6000 V in steps of 50 V]
DC test voltage	U test [500 V 6000 V in steps of 50 V]
Duration of starting voltage	t start [1 s 120 s]
Duration of ramp	t ramp [2 s 60 s]
Duration of test voltage	t end [Off, 1 s 120 s]

Test limits

High limit (I)	H limit [0.05 mA 10.0 mA]
Low limit (I)	L limit [Off, 0.05 mA 10.0 mA]

Test circuit




Figure 6.33: HV DC programmable test

HV DC programmable test procedure

- Select the HV DC programmable function.
- Set test parameters / limits.
- Connect HV test leads to HV(~,+) and HV(~,-) terminals on the instrument.
- Connect HV test leads to device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.34: Examples of HV DC programmable test results

Note:

•

First HV measurement after power on the instrument (if password protection is enabled) or first HV measurement after enabling or changing password require entering password for enabling HV test. Refer to chapter 4.6.7 Change password for HV functions for more information.

6.2.7 Insulation resistance (Riso, Riso-S)




Figure 6.35: Insulation resistance test menus

Test results / sub-results

Riso..... Insulation resistance Riso-S Insulation resistance-S Um...... Test voltage

Test parameters

Nominal test voltage	Uiso [50 V, 100 V, 250 V, 500 V, 1000 V]
Duration	Duration [Off, 2 s 180 s]
Type of test	Type [Riso, Riso-S, (Riso, Riso-S)]
Output connections (Riso)	[ISO(+), ISO(-), Socket LN-PE, Socket LN-P/S]
Output connections (Riso-S)	[Socket LN-P/S]

Test limits

H Limit (Riso)	Η limit [Off, 0.10 MΩ 10.0 MΩ]
L Limit (Riso)	L limit [Off, 0.10 MΩ 10.0 MΩ]
H Limit (Riso-S)	H limit [Off, 0.10 MΩ 10.0 MΩ]
L Limit (Riso-S)	L limit [Off, 0.10 MΩ 10.0 MΩ]

Test circuits




Figure 6.36: Measurement of insulation resistance (ISO(+), ISO(-))




Figure 6.37: Measurement of insulation resistance (Socket LN - PE)




Figure 6.38: Measurement of Riso, Riso-S (socket)

RISO measurement procedure

- Select the Riso function.
- Set test parameters / limits.
- Connect test leads to ISO(+), ISO(-) terminals on the instrument, then connect test leads to device under test, or
- Connect device to mains test socket. For Riso-S test, additionally connect test lead to P/S terminal on instrument, and then connect test lead to device.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.39: Examples of Insulation resistance measurement results

Note:

When P/S probe is connected during the Riso measurement, then the current through it is also considered.

6.2.8 Sub-leakage (Isub, Isub-S)



Figure 6.40: Sub Leakage test menus

Test results / sub-results

Isub Sub-leakage current Isub-S...... Sub-leakage current-S

Test parameters

Type of test	Type [Isub, Isub-S, (Isub, Isub-S)]
Output voltage	Output [40 Vac]
Duration	Duration [Off, 2 s 180 s]
Output connections (Isub)	[SUB1, SUB2, Socket LN-PE, Socket LN-P/S]
Output connections (Isub-S)	[Socket LN-P/S]

Test limits

H Limit (Isub)	H limit [Off, 0.25 mA 15.0 mA, Custom]
L Limit (Isub)	L limit [Off, 0.25 mA 15.0 mA, Custom]
H Limit (Isub-S)	H limit [Off, 0.25 mA 15.0 mA]
L Limit (Isub-S)	L limit [Off, 0.25 mA 15.0 mA]

Test circuits




Figure 6.41: Measurement of Sub-leakage (SUB1, SUB2)




Figure 6.42: Measurement of Sub-leakage (socket LN-PE)




Figure 6.43: Measurement of Sub-leakage, Sub-leakage-S (socket)

Sub-leakage measurement procedure

- Select the **Sub-leakage** function.
- Set test parameters / limits.
- Connect test leads to SUB1,SUB2 terminals on the instrument, then connect test leads to device under test, or
- Connect device under test to mains test socket. For Isub-S test, additionally connect test lead to P/S terminal on the instrument, and then connect test lead to a device.
- Start measurement.
- Measurement can be stopped manually or by timer.

Save results (optional).



Figure 6.44: Examples of Sub-leakage measurement results

Note:

•

When P/S probe is connected during the Sub-leakage measurement, then the current through it is also considered.

6.2.9 Differential Leakage

스 Differential Leakage		13:30
ldiff	mA	
PW		?
Duration Change Delay	Off YES 5 s	
H Limit(ldiff) L Limit(ldiff)	Off Off	

Figure 6.45: Differential Leakage test menu

Test results / sub-results

Idiff Differential Leakage current P..... Power

Test parameters

Duration	Duration [Off, 2 s 180 s]
Change status	Change [YES, NO]
	YES: The instrument measures leakage current in two sequential steps with delay* in between. The phase voltage is firstly applied to the right live output of the mains test socket and secondly to the left live output of the mains test socket. NO: The phase voltage is applied only to the right live output of the mains test socket.
*Delay time	Delay [0.2 s 5 s]

Test limits

H Limit (Idiff)	H limit [Off, 0.25 mA 15.0 mA, Custom]
L Limit (Idiff)	L limit [Off, 0.25 mA 15.0 mA, Custom]
Output connections	[Socket L,N – PE,P/S]

Test circuit




Figure 6.46: Measurement of Differential Leakage current

Differential Leakage measurement procedure

- Select the Differential Leakage function.
- Set test parameters / limits.
- · Connect device under test to mains test socket and optionally to P/S terminal.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).

Differential Leakage	13:32	🗂 Differential Leakage	13:37
0.01 🗸		076 X	
P 157.1w		P 151.6w	
Duration 2 s Change YES Delay 5 s	F	Duration 2 s Change YES Delay 5 s	F
H Limit(ldiff) 0.50 mA L Limit(ldiff) Off	444	H Limit(ldiff) 0.50 mA L Limit(ldiff) Off	

Figure 6.47: Examples of Differential Leakage measurement results

6.2.10 lpe Leakage




Figure 6.48: Ipe Leakage test menu

Test results / sub-results

Ipe PE current P..... Power

Test parameters

Duration	Duration [Off, 2 s 180 s]
Change status	Change [YES, NO]
-	YES: The instrument measures leakage current in two sequential steps with delay* in
	between. The phase voltage is firstly applied to the right live output of the mains
	test socket and secondly to the left live output of the mains test socket.
	NO: The phase voltage is applied only to the right live output of the mains test socket.
*Delay time	Delay [0.2 s 5 s]
Output connections	[Socket L,N – PE]

Test limits

H Limit (Ipe)	H limit [Off, 0.25 mA 15.0 mA, Custom]
L Limit (Ipe)	L limit [Off, 0.25 mA 15.0 mA, Custom]

Test circuit




Figure 6.49: Measurement of Ipe Leakage current

Ipe Leakage measurement procedure

- Select the Ipe Leakage function.
- Set test parameters / limits.
- · Connect device under test to mains test socket.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).

스 Ipe Leakage	13:39	♪ Ipe Leakage	13:41
0 02 🗸		1 50 X	
Ipe 0.02 _{mA}		Ipe 1.50 mA ×	
P 153.8w		P 151.1w	
Duration 2 s Change YES Delay 0.2 s	F	Duration 2 s Change YES Delay 0.2 s	F
H Limit(lpe) 1.00 mA L Limit(lpe) Off		H Limit(lpe) 1.00 mA L Limit(lpe) Off	

Figure 6.50: Examples of Ipe Leakage measurement results

6.2.11 Touch Leakage




Figure 6.51: Touch Leakage test menu

Test results / sub-results

Itou Touch Leakage current P..... Power

Test parameters

Duration	Duration [Off, 2 s 180 s]
Change status	Change [YES, NO]
	 YES: The instrument measures leakage current in two sequential steps with delay* in between. The phase voltage is firstly applied to the right live output of the mains test socket and secondly to the left live output of the mains test socket. NO: The phase voltage is applied only to the right live output of the mains test socket.
*Delay time	Delay [0.2 s 5 s]
Output connections	[Socket L,N – PE,P/S]

Test limits

H Limit (Itou)	H limit [Off, 0.25 mA 15.0 mA]
L Limit (Itou)	L limit [Off, 0.25 mA 15.0 mA]

Test circuit




Figure 6.52: Measurement of Touch Leakage current

Touch Leakage measurement procedure

- Select the **Touch Leakage** function.
- Set test parameters / limits.
- Connect device under test to mains test socket. Connect test lead to P/S terminal on the instrument and on device under test.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.53: Examples of Touch Leakage measurement results

6.2.12 Power

← Power			08:59
PW	THDu	%	
\$VA	THDi	A	E
QVAr	CosΦ		
PF	1.00	A	?
	U	V	
Duration			
H Limit(P) L Limit(P)	0		

Figure 6.54: Power measurement menu

Test results / sub-results

Q PF THDu	Apparent power Reactive power Power factor Total harmonic distortion – voltage Total harmonic distortion – current cosinus Φ
l	Load current
U	Voltage

Test parameters

Duration	ration [Off, 2 s 180 s]
Output connections [So	ocket L–N]

Test limits

H Limit (P)	H limit [Off, 10 W 3.50 kW, Custom]
L Limit (P)	L limit [Off, 10 W 3.50 kW, Custom]

Test circuit




Figure 6.55: Measurement of Power

Power measurement procedure

- Select the **Power** function.
- Set test parameters / limits.
- Connect device under test to mains test socket.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).



Figure 6.56: Examples of Power measurement results

6.2.13 Leak's & Power

Ð	Leak's & P	ower		13:46
P	W	THDu	%	
ltou Idiff	mA mA	THDi CosФ	A 	=
S Q	VA VAr	l U	A V	?
PF Durat			Off	
Change Delay H Limit(P)		۲	ves 5 s Off	444

Figure 6.57: Leak's & Power measurement menu

Test results / sub-results

P	
Itou	Touch Leakage current
Idiff	Differential Leakage current
S	Apparent power
Q	Reactive power
PF	Power factor
THDu	Total harmonic distortion – voltage
THDi	Total harmonic distortion – current
Cos Φ	cosinus Φ
I	Load current
U	Voltage

Test parameters

Duration	Duration [Off, 2 s 180 s]
Change status	 Change [YES, NO] YES: The instrument measures leakage current in two sequential steps with delay* in between. The phase voltage is firstly applied to the right live output of the mains test socket and secondly to the left live output of the mains test socket. NO: The phase voltage is applied only to the right live output of the mains test socket.
*Delay time	Delay [0.2 s 5 s]
Output connections	[Socket L–N, Socket L,N – PE,P]

Test limits

H Limit (P)	H limit [Off, 10 W 3.50 kW, Custom]
L Limit (P)	L limit [Off, 10 W 3.50 kW, Custom]
H Limit (Idiff)	H limit [Off, 0.25 mA 15.0 mA, Custom]
L Limit (Idiff)	L limit [Off, 0.25 mA 15.0 mA, Custom]
H Limit (Itou)	H limit [Off, 0.25 mA 15.0 mA]
L Limit (Itou)	L limit [Off, 0.25 mA 15.0 mA]

Test circuit




Figure 6.58: Measurement of Leak's and Power

Leak's & Power measurement procedure

- Select the Leak's & Power function.
- Set test parameters / limits.
- · Connect device under test to mains test socket and optionally to P/S terminal.
- Start measurement.
- Measurement can be stopped manually or by timer.
- Save results (optional).

📩 Leak's & Power	13:48	🖆 Leak's & Power	09:38
P 1927 W 💙 THDu 2.3 %		P 2.34 kW 🗙 THDu 2.5 %	
Itou 0.00 mA THDi 199 mA Idiff 0.00 mA CosΦ 1.00c		Itou 0.00 mA 🗸 THDi 255 mA Idiff 0.00 mA 🗸 CosФ 1.00i	
s 1928 VA I 8.57 A Q 41.4 VAr U 225 V		s 2.34 kVA I 10.54 A Q 81.5 VAr U 222 V	
PF 1.00c Duration 3 s	P	PF 1.00i Duration 3 s	F
Change YES Delay 5s	444	Change YES Delay 5s H Limit(P) 2.00 kW	444

Figure 6.59: Examples of Leak's & Power measurement results

6.2.14 Discharging Time

Discharging Time	
ts	?
Up V	
Limit U 60 V Output External	
Limit(t) 1 s	•••

Figure 6.60: Discharging Time test menu

Test results / sub-results

t Discharging time Up..... Peak voltage of supply during the test

Test parameters

Limit voltage	Limit U [34 V, 60 V, 120 V]
Output connections	Output [External, Socket]
Test mode	Mode [Manual, Auto]
Delay time for AUTO mode	Delay [2 s 30 s]

Test limits

Discharging time limit	Limit(t) [1 s. 5 s]	
Discharging time limit		

Measuring principle (Output = External)

The measuring principle of the Discharging time function is as following:

Phase 🛈	The device under test is connected to supply voltage via an external socket. The instrument monitors the voltage (on supply or internal connections) and internally stores the peak voltage value.
Phase 2	The device under test is disconnected from the supply and the voltage at the test terminals starts to fall. Once the rms voltage falls for 10 V the instrument starts the timer.
Phase ③	After the voltage drops below an internally calculated voltage value the timer is stopped. The instrument re-calculates the measured time to a value as it would be if the disconnection occurred at the maximum voltage value.




Figure 6.61: Measuring principle (external)

Test circuit (Output = External)




Figure 6.62: Discharging Time test (Output = External)

Discharging Time test procedure (Output = External)

- Select the **Discharging Time** function.
- Set test parameters / limits.
- · Connect test leads to the DISCHARGING TIME terminals on the instrument and on the device under test.
- · Connect device under test to the mains supply and Switch it ON.
- Start measurement.
- · Measurement is stopped manually by disconnecting device under test mains supply.
- Save results (optional).



Figure 6.63: Examples of Discharging Time measurement results (Output = External)

Measuring principle (Output = Socket)

The measuring principle of the Discharging time function is as following:

- **Phase** The DEVICE UNDER TEST is connected to the mains test socket. The instrument monitors the mains voltage and internally stores the peak voltage value.
- **Phase** The instrument disconnects the DEVICE UNDER TEST from the supply and the voltage at the supply connections starts to fall. Disconnection moment is always at peak voltage.
- **Phase 3** After the voltage drops below the limit value the timer is stopped.

Test circuit (Output = Socket)




Figure 6.64: Discharging Time test (Output = Socket)

Discharging Time test procedure (Output = Socket)

- Select the **Discharging Time** function.
- Set test parameters / limits.
- Connect the device under test to the mains test socket on the instrument.
- Start measurement.
- Measurement can be stopped manually or automatically.
- Save results (optional).

Discharging Time	13:31	Discharging Time	09:45
		E 6 🗙	
t 0.0 s 🗸		t disch 5.6 s ×	
Up 326 V	?	Up 337 V UIn:	?
Limit U 60 V		Limit U 60 V Output Socket	
Mode Manual Limit(t) 1 s		Mode Manual Limit(t disch) 1 s	• • •

Figure 6.65: Examples of Discharging Time measurement results (Output = Socket)

6.2.15 Functional inspections

Inspection	11:25	▲ Inspection	11:26
Functional		Functional	
mechanical operation	□ ?	mechanical operation	Р
electrical operation		electrical operation	
safety relevant functions		safety relevant functions	$\mathbf{\tilde{\mathbf{v}}}$
			×
			•••

Figure 6.66: Functional inspection start menu (left) and menu during inspection (right)

Test parameters (optional)

For the optional Power measurement test the parameters and limits are the same as set in the Power single test, see chapter 6.2.12 Power.

Test circuit




Figure 6.67: Functional inspection

Functional inspection procedure

- Select the appropriate Functional inspection.
- Start the inspection.
- Perform the functional inspection of the appliance / equipment.
- > Perform the Power measurement test through the mains test socket (optional).
- Apply appropriate ticker(s) to items of inspection.
- End the inspection.
- Save results (optional).



Figure 6.68: Examples of Functional Inspection results

7 Auto Sequences[®]

Preprogrammed sequences of measurements can be carried out in Auto Sequences® menu. The sequence of measurements, their parameters and flow of the sequence can be programmed. The results of an Auto Sequence[®] can be stored in the memory together with all related information. Auto Sequences[®] can be pre-programmed on PC with the MT Link software and uploaded to the instrument. On the instrument parameters and limits of individual single test in the Auto Sequence® can be changed / set.

7.1 Selection of Auto Sequences®

Required Auto Sequence[®] group from Auto Sequence[®] groups menu should be selected first. Refer to Chapter 4.9 Auto Sequence[®] groups for more details. Auto Sequence[®] to be carried out can then be selected from the Main Auto Sequences[®] menu, which can be organized


in structural manner with folders and sub-folders containing Auto Sequences®.


Searching by name or short code is also possible within the active Auto Sequence® group. Refer to Chapter 7.1.2 Searching in Auto Sequences® menu for details.

7.1.1 Selecting an active Auto Sequence[®] group in Auto Sequences[®] menu

Auto Sequences[®] and Auto Sequence[®] group menus are interconnected so an active Auto Sequence[®] group can be also selected in the Auto Sequences® menu.

Procedure





New Auto Sequence[®] group is selected and all folders, sub-folders and Auto Sequences[®] within that group are displayed on the screen.

7.1.2 Searching in Auto Sequences® menu

In Auto Sequence[®] menu it is possible to search for Auto Sequences[®] on base of their Name or Short code.

Procedure Auto Sequences® Select Auto Sequence[®] group header in Auto 13:23 (1)Sequences® menu by taping on it. Demo Group Of Auto tests E Portable / Handheld Equipment Q Class 1 DEM01 Live Test DEMO2 Dead Test 🗉 📄 Class 2 Select Search from options menu to open Search setup 2 menu. Search 14:05 The parameters that can be searched for are displayed 3 in the Search setup menu. Q Short code The search can be narrowed by entering a text in the 3a Name Name and Short code fields. Short code Strings can be entered by using the on-screen 14:05 keyboard. ŵ à S D G Ĥ J Ř shift z x C ý É. Ň Ň end Clears all filters. Sets filters to default value. 3b



Q


Searches through the active Auto Sequence $^{\ensuremath{\mathbb{R}}}$ group according to the set filters.

The results are shown in the Search results screen presented on *Figure 7.1 and Figure 7.2*.






Options



Note:

Search result page consist of up to 50 results.





Options



7.1.3 Structure organization of Auto Sequence[®] group

The Auto Sequences[®] to be carried out can be selected from the active group in Main Auto Sequences[®] menu. This menu can be organized in a structural manner with folders, sub-folders and Auto Sequences[®]. Auto Sequence[®] in the structure can be the original Auto Sequence[®] or a shortcut to the original Auto Sequence[®].

Auto Sequences[®] marked as shortcuts and the original auto Sequences[®] are coupled. Changing of parameters or limits in any of the coupled Auto Sequences[®] will influence on the original Auto Sequence[®] and all its shortcuts.




Figure 7.3: Structure organization of Auto Sequence[®] group, Auto Sequence[®] selected

Options

DEMO	The original Auto Sequence [®] .
DEMO_Shortcut	A shortcut to the original Auto Sequence [®] .
iq	Enters menu for more detail view of selected Auto Sequence [®] . This option should also be used if the parameters / limits of the selected Auto Sequence [®] have to be changed. Refer to chapter <i>7.2.1 Auto Sequence[®] view</i> menu for more information.
	Starts the selected Auto Sequence [®] . The instrument immediately starts the Auto Sequence [®] .

7.2 Organization of Auto Sequence[®] tests

An Auto Sequence® test is divided into three phases:

- Before starting the first test the Auto Sequence[®] view menu is shown (unless it was started directly from the Main Auto Sequence[®] menu). Parameters and limits of individual measurements can be set in this menu.
- During the execution phase of an Auto Sequence[®], pre-programmed single tests are carried out. The sequence of single tests is controlled by pre-programmed flow commands.
- After the test sequence is finished the Auto Sequence[®] result menu is shown. Details of individual tests can be viewed and the results can be saved to Memory organizer.

7.2.1 Auto Sequence® view menu

In the Auto Sequence[®] view menu the header and the single tests of selected Auto Sequence[®] are displayed. The header contains Name, Short code (if set) and description of the Auto Sequence[®]. Before starting the Auto Sequence[®], test parameters / limits of individual measurements can be changed.

7.2.1.1 Auto Sequence[®] view menu (header is selected)




Figure 7.4: Auto Sequence® view menu – header selected

Options



Starts the Auto Sequence®.

7.2.1.2 Auto Sequence[®] view menu (measurement is selected)





Figure 7.5: Auto Sequence[®] view menu – measurement selected

R iso x3	Selects single test.
Sub-leakage	
Power	
	Opens menu for changing parameters and limits of selected measurements.
	Refer to chapter 6.1.1.2 Setting parameters and limits of single tests for more information how to change measurement parameters and limits.
Type Riso Uiso 100 V Duration 2 s L Limit(Riso) 0.59 MD H Limit(Riso) 0.69 MD L Limit(Riso-5) 0ff H Limit(Riso-5) 0ff	
	Starts the selected Auto Sequence [®] .
?	Opens the Help menu of selected test.
	Selects Multiple points.
Multiple points	



7.2.1.3 Indication of Loops



The attached 'x3' at the end of single test name indicates that a loop of single tests is programmed. This means that the marked single test will be carried out as many times as the number behind the 'x' indicates. It is possible to exit the loop before, at the end of each individual measurement.

7.2.1.4 Managing multiple points

If the device under test has more than one test point for an individual single test and the selected Auto Sequence® predicts only one test point (one single test) it is possible to change the Auto Sequence® appropriately. Single tests with enabled Multiple points ticker will be executed in a continuous loop. It is possible to exit the loop anytime at the end of each individual measurement.

The Multiple points setting is valid only for the actual Auto Sequence[®]. If the user often tests appliances with more than one test points it is recommended to program a special Auto Sequence[®] with pre-programmed loops.

7.2.2 Step by step excecution of Auto Sequences®

While the Auto Sequence[®] is running it is controlled by pre-programmed flow commands. Examples of actions controlled by flow commands are:

- pauses during the test sequence
- monitoring of input pins
- control of lamps, test adapters and other external devices
- proceeding of test sequence in regard to measured results
- etc.

The actual list of flow commands is available on chapter **E.5 Description of flow commands**.

♪ Demo	17:50
Subleakage test. Test will continue in 1 s.	
rest will continue in 1 s.	

Figure 7.6: Auto Sequence[®] – example of a pause with message




Figure 7.7: Auto Sequence[®] – example of a finished measurement with options for proceeding

Options (during execution of an Auto Sequence®)

	Proceeds to next step in the test sequence. Repeats the measurement if multiple points execution is selected. Displayed result of a single test will be stored.
C	Repeats the measurement. Displayed result of a single test will not be stored.
	Ends the Auto test and goes to Auto test result screen. Refer to chapter 7.2.3 Auto Sequence [®] result screen for more information.
Ŷ	Exits the loop of single tests (pre-programmed loop or multiple points execution) and proceeds to the next step in the test sequence.
	Opens menu for viewing parameters and limits of a current measurement.
Type Riso Uiso 100 V Duration 2 s L Limit(Riso) 10.0 M0 L Limit(Riso-S) Off H Limit(Riso-S) Off	
	Adds comment. The instrument opens keypad for entering a comment to a current measurement.


The offered options in the control panel depend on the selected single test, its result and the programmed test flow.

Note:

 During Auto Sequence[®] the popup Warning messages (see chapter 4.4 Symbols and messages) are displayed only before the single test inside one Auto Sequence[®]. This default setting can be changed with appropriate flow command. For more information about programming Auto Sequences[®] refer to chapter Appendix E -Programming of Auto Sequences[®] on MT Link.

7.2.3 Auto Sequence® result screen

After the Auto Sequence[®] is finished the Auto Sequence[®] result screen is displayed as presented on *Figure 7.8*. At the left side of the display the single tests and their statuses are shown. In the middle of the display the header of the Auto Sequence[®] is displayed and at the top the overall Auto Sequence[®] status is displayed. Refer to chapter *5.1.1 Measurement statuses* for more information.





Options

Options	
	Start Test Starts a new Auto Sequence [®] .
	View results of individual measurements. The instrument goes to menu for viewing details of the Auto Sequence [®] , see <i>Figure 7.9</i> .
F	Adds comment to the Auto Sequence [®] . The instrument opens keypad for entering a comment.
	Saves the Auto Sequence [®] results.
	A new Auto Sequence [®] was selected and started from a Structure object in the structure tree:
	 The Auto Sequence[®] will be saved under the selected Structure object.
	A new Auto Sequence [®] was started from the Auto Sequence [®] main menu:
	 Saving under the last selected Structure object will be offered by default. The user can select another Structure object or create a new Structure object. By pressing organizer menu the Auto Sequence[®] is saved under selected location.
	An empty measurement was selected in structure tree and started:
	 The result(s) will be added to the Auto Sequence[®]. The Auto Sequence[®] will change its overall status from 'empty' to 'finished'.
	An already carried out Auto Sequence® was selected in structure tree, viewed and then restarted:
	 A new Auto Sequence[®] will be saved under the selected Structure object.
	Print label.
لي	See chapter 4.6.9 Devices for details how to enable and set the printer. For more information refer to chapter Appendix C - Print labels and write / read RFID / NFC tags.
	Print and Save Auto Sequence® results simultaneously. Option is available if Devices parameter Auto save is set to On print, se chapter 4.6.9 Devices for more information.
é	Write RFID/NFC tag. Refer to Appendix C - Print labels and write / read RFID / NFC tags for supported tag types.



Write RFID / NFC tag and Save Auto Sequence® results simultaneously. Option is available if Devices parameter Auto save is set to On write, see chapter *4.6.9 Devices* for more information.

Note:

Options menu content depends on Devices settings menu. If no writing device is set, than 'Print label' and 'Write RFID' icons are hidden. Only one writing device can be set at the same time.

Options (menu for viewing details of Auto Sequence[®] results):

ī	Details of selected single test in Auto Sequence [®] are displayed, see <i>Figure 7.9.</i>
	Adds comment to the selected single test in Auto Sequence [®] . The instrument opens keypad for entering a comment.
	View parameters and limits of selected single test.

🗅 Results: I	DEMO	11:37	T R iso 1	11:39
R iso 📃	\checkmark	iā		=
R iso 🛛 🔵	10.Jan.2017 11:35:35 Short code: U123	F	Riso >199.9 _{MΩ}	F
R iso 😑	Basic demo of Auto Sequence. Includes:		Um 525∨	
Sub-leakage 🔵	-Loop -Pause -End of test operation		Type Riso Uiso 500 V	
Power 😑			Duration 2 s L Limit(Riso) 1.00 MΩ	
		444	H Limit(Riso) Off	•••

Figure 7.9: Details in Auto Sequence[®] results menu screens

7.2.4 Auto Sequence® memory screen

In Auto Sequence[®] memory screen details of the auto test can be viewed, labels can be printed and a new Auto Sequence[®] can be restarted.

Semory 1/1: DEMO		11:40
R iso 😑	\checkmark	C
R iso 😑	10.Jan.2017 11:35:35 Short code: U123	īQ
R iso 😑	Basic demo of Auto Sequence. Includes:	Ģ
Sub-leakage 🔵	-Loop -Pause -End of test operation	
Power 😑		•••

Figure 7.10: Auto Sequence® memory screen

Options

Options	
C	Retest the Auto Sequence [®] . Enters menu for a new Auto Sequence [®] .
iā	Enters menu for viewing details of the Auto Sequence [®] . Refer to chapter 7.2.3 Auto Sequence [®] result screen for more information.
Ē	Print label. See chapter 4.6.9 Devices for details how to enable and set the printer. For more information refer to chapter Appendix C - Print labels and write / read RFID / NFC tags.
é	Write RFID/NFC tag. All data including Auto Sequence [®] results are written to the RFID/NFC writing device. Refer to chapter <i>Appendix C - Print labels and write / read RFID / NFC tags</i> for supported tag types.

Note:

Options menu content depends on Devices settings menu. If no writing device is set, than 'Print label' and 'Write RFID' icons are hidden. Only one writing device can be set at the same time.

8 Maintenance

8.1 Periodic calibration

It is essential that all measuring instruments are regularly calibrated in order for the technical specification listed in this manual to be guaranteed. We recommend an annual calibration.

8.2 Fuses

There are four fuses on the front panel:

F1, F2: F 5 A / 250 V / (20×5) mm / 1500 A: intended for instrument protection. For position of fuses refer to chapter 3.1 Front panel.

F3, F4: T 16 A / 250 V / $(32 \times 6,3)$ mm / 1500 A: protection against over-currents through mains test socket. For position of fuses refer to chapter 3.1 Front panel.

Warnings!

- Switch off the instrument and disconnect all test accessories and mains cord before replacing the fuses or opening the instrument.
- Replace blown fuses only with the same types defined in this document.

8.3 Service

For repairs under or out of warranty please contact your distributor for further information.

Unauthorized person is not allowed to open the C.A 6165 instrument. There are no user replaceable parts inside the instrument.

8.4 Cleaning

Use a soft, slightly moistened cloth with soap water or alcohol to clean the surface of C.A 6165 instrument. Leave the instrument to dry totally before using it.

Notes:

- Do not use liquids based on petrol or hydrocarbons!
- Do not spill cleaning liquid over the instrument!

9.1 USB and RS232 communication with PC

The instrument automatically selects the communication mode according to detected interface. USB interface has priority.

How to establish an USB or RS-232 link:

•	RS-232 communication: connect a PC COM port to the instrument RS232-2 connector using the RS232 serial communication cable;
•	USB communication: connect a PC USB port to the instrument USB connector using the USB interface cable.
•	Switch on the PC and the instrument.
•	Run the MT Link software.
•	Select communication port.
•	The PC and the instrument will automatically recognize each other.
•	The instrument is prepared to communicate with the PC.

MT Linkis a PC software running on Windows 7, Windows 8, Windows 8.1 and Windows 10.

9.2 Bluetooth communication

The internal Bluetooth module enables easy communication via Bluetooth with PC and Android devices.

How to configure a Bluetooth link between instrument and PC

•	On PC configure a Standard Serial Port to enable communication over Bluetooth link between instrumen
	and PC. Usually no code for pairing the devices is needed.
•	Run the MT Link software.
•	Select configured communication port.
•	The PC and the instrument will automatically recognize each other.
•	The instrument is prepared to communicate with the PC.

Switch On the instrument. Some Android applications automatically carry out the setup of a Bluetooth connection. It is preferred to use this option if it exists. This option is supported by Chauvin Arnoux's Android applications.

 If this option is not supported by the selected Android application then configure a Bluetooth link via Android device's Bluetooth configuration tool. Usually no code for pairing the devices is needed.
 The instrument and Android device are ready to communicate.

Notes

- Sometimes there will be a demand from the PC or Android device to enter the code. Enter code 'NNNN' to correctly configure the Bluetooth link.
- The name of correctly configured Bluetooth device must consist of the instrument type plus serial number, eg. CA 6165-12240429I. If the Bluetooth module got another name, the configuration must be repeated.
- In case of serious troubles with the Bluetooth communication it is possible to reinitialize the internal Bluetooth module. The initialization is carried out during the Initial settings procedure. In case of a successful initialization "INITIALIZING... OK!" is displayed at the end of the procedure. See chapter 4.6.10 Initial Settings.
- Check if there are available Chauvin Arnoux Android applications for this instrument.

9.3 Bluetooth communication with printers and scanners

The C.A 6165 instrument can communicate with supported Bluetooth printers and scanners. Contact Chauvin Arnoux or your distributor which external devices and functionalities are supported. See Chapter *4.6.9 Devices* for details how to set the external Bluetooth devices.

9.4 Ethernet communication

The instrument is also capable of communicating through an Ethernet port. The Ethernet communication must be fully configured in the setting menu before first use. See chapter *4.6.8 Settings* for details. MT Linkis currently **not** supporting Ethernet communication. Contact Chauvin Arnoux or your distributor regarding options for using the Ethernet communication.

9.5 RS232 communication with other external devices

It is possible to communicate with scanners via the RS232-1 serial port and printers via the RS232-2 serial port. Contact Chauvin Arnoux or your distributor which external devices and functionalities are supported.

9.6 Connections to test adapters

9.6.1 Test connector TC1

The 8 pin test connector TC1 is intended for connection of external test adapters. TC1 consists of Measuring signal connector and Communication signal connector.




Figure 9.1: Test connector TC1 layout

Legend:

4 pin measuring signal connection (Safety connector)

1	In parallel to terminal N on mains test socket
2	In parallel to terminal L on mains test socket
3	In parallel to terminal PE on mains test socket
4	In parallel to terminal P/S

4 pin communication signal connection¹⁾ (USB type connector)

5	Rx,	Tx,	+5V,	GND	
-	,		- ,	-	

Note

 ¹⁾Do not connect USB communication cable to 4 pin communication signal connector. It is intended only for connection to test adapters.

9.7 INPUTs

The DB9 connector INPUTs is intended for connection of external control signals.




Figure 9.2: INPUT connector - pin layout

Legend	d:		
Pin		Description	Туре
5	EXTERNAL OK KEY mode	Input for Remote control pedal	
6	IN_2	External input 2	Input low: < 1 V d.c. against earth
7	IN_3	External input 3	Input high: > 4.5 V d.c. against earth
8	IN_4	External input 4	Umax: 24 V a.c, d.c against earth
4	IN_5	External input 5	
9		GND	
3		Instrument reset pin	
1,2		Not supported	

9.8 OUTPUTs

Via the DB9 connector OUTPUT four control signals for external devices are provided.




Figure 9.3: OUTPUT connector - pin layout

Pins				Description	Туре
4,9	1.5 A	DB9 - 4 DB9 - 9	OUT_1	Control output 1	NO relay, Umax: 24V, Imax: 1.5 A Output low: open contact Output high: closed
3,8	1.5 A	DB9 - 3 DB9 - 8	OUT_2	Control output 2	contact
2,7	1.5 A	DB9 - 2 DB9 - 7	OUT_3	Control output 3	
1,6	1.5 A	DB9 - 1 DB9 - 6	OUT_4	Control output 4	
5			+5 V	Supply for inputs	

10 Technical specifications

10.1 HV AC, HV AC programmable

Voltage a.c.

	Range	Resolution	Accuracy
U	0 V 1999 V	1 V	±(3 % of reading)
	2.00 kV 5.99 kV	10 V	±(3 % of reading)

Current a.c. (apparent)

	Range	Resolution	Accuracy
Ι	0.0 mA 99.9 mA	0.1 mA	\pm (3 % of reading + 3 D)

Current a.c.(capacitive, resistive)

	Range	Resolution	Accuracy
Ir	0.0 mA 99.9 mA	0.1 mA	Indicative
lc	-99.9 mA 99.9 mA	0.1 mA	Indicative

Output voltage	100 V 1000 V (-0/+10%),
	1010 V 5000 V (-0/+5%) floating to earth
Trip out time (if apparent current exceeds high limit)	
Short circuit current	> 200 mA
Output power	500 VAmax

Test terminals Connections Function Connections Withstanding voltage (HVAC, HVAC-P) HV(~,+) ↔ HV(~,-)

10.2 HV DC, HV DC programmable

Voltage d.c.

	Range	Resolution	Accuracy
U	0 V 1999 V	1 V	±(3 % of reading)
	2.00 kV 6.99 kV	10 V	±(3 % of reading)

Current d.c.

$1 = 0.01 \text{ mA} = 9.99 \text{ mA} = 0.01 \text{ mA} = \pm (5\% \text{ of reading + 3 D})$		Range	Resolution	Accuracy
	Ι	0.01 mA 9.99 mA	0.01 mA	\pm (5 % of reading + 3 D)

Output voltage	500 V 1000 V (-0/+10%),
Ripple voltage	
Trip out time (if current exceeds high limit)	
Max. capacitive load	

Test terminals Connections Function Connections Withstanding voltage (HVDC, HVDC-P) HV(~,-) ↔ HV(~,-)

10.3 Continuity

Continuit	ty		
	Range	Resolution	Accuracy
	0.00 Ω 19.99 Ω	0.01 Ω	\pm (2 % of reading + 2 D)
D	20.0 Ω 99.9 Ω	0.1 Ω	\pm 3 % of reading
n	100.0 Ω 199.9 Ω	0.1 Ω	\pm 5 % of reading
	200 Ω 999 Ω	1 Ω	indicative

Voltage drop (lout = 10 A)

[Range	Resolution	Accuracy
	ΔU	0.00 V 19.99 V	0.01 V	\pm (2 % of reading + 5 D)
		20.0 V 99.9 V	0.1 V	± 3 % of reading

Limit value of voltage drop versus wire cross-section:

Wire cross-section (mm ²)	Limit voltage drop (V)
0.5	5.0
0.75	5.0
1	3.3
1.5	2.6
2.5	1.9
4	1.4
≥6	1.0

Operating range (acc. to EN 61557-4) Test currents	
Current source (at nominal mains voltage, use	e of standard accessories)
	0.2 A at R < 8 Ω
	4 A at R < 1 Ω
	10 A at R < 0.5 Ω
	25 A at R < 0.2 Ω
Open circuit voltage	< 6 V a.c.
Max current lead resistance	40 Ω
Test lead compensation (P/S – PE)	up to 5 Ω
Test method: Continuity 4 wire	Kelvin method, floating to earth
Test method: Continuity P/S – PE	2 wire test, floating to earth

Test terminals

Function	Connections
Continuity P/S – PE	$P/S \leftrightarrow$ Mains test socket (PE), TC1
Continuity 4 wire	P1/C1 ↔ P2/C2

10.4 Insulation Resistance, Insulation Resistance-S

Insulation resistance, Insulation resistance -S (250 V, 500 V, 1000 V)

	Range	Resolution	Accuracy
Riso	0.00 ΜΩ 19.99 ΜΩ	0.01 MΩ	\pm (3 % of reading + 2 D)
Riso-S	20.0 ΜΩ 199.9 ΜΩ	0.1 MΩ	± 10 % of reading

Insulation resistance, Insulation resistance -S (50 V, 100 V)

	Range	Resolution	Accuracy
Riso	0.00 ΜΩ 19.99 ΜΩ	0.01 MΩ	\pm (5 % of reading + 2 D)
Riso-S	20.0 ΜΩ 99.9 ΜΩ	0.1 MΩ	± 20 % of reading

Output voltage

	Range	Resolution	Accuracy	
Um	0 V 1200 V	1 V	\pm (3 % of reading + 2 D)	

Operating range (acc. to EN 61557-2)	. 0.08 ΜΩ 199.9 ΜΩ
Nominal voltages Un (d.c.)	. 50 V, 100 V, 250 V, 500 V, 1000V (- 0 %, + 10 %)
Short circuit current	. max. 2.0 mA

Test terminals

Function	Connections
Insulation	Mains test socket (LN), ISO(+) \leftrightarrow Mains test socket (PE), ISO(-),
	TC1
Insulation – S	Mains test socket (LN), ISO(+) \leftrightarrow P/S, TC1

10.5 Substitute Leakage Current, Substitute Leakage Current - S

Substitute leakage current, Substitute leakage current - S

	Range	Resolution	Accuracy
Isub Isub-S	0.00 mA 19.99 mA	10 µA	\pm (5 % of reading + 3 D)

Operating range (acc. to EN 61557-16)0.12 mA ... 19.99 mA

Open circuit voltage.....< 50 V a.c.

Current calculated to mains supply voltage (110 V or 230 V) is displayed.

Test terminals:

Function	Connections
Subleakage	Mains test socket (LN), SUB1 ↔ Mains test socket (PE), SUB2,
	TC1
Subleakage – S	Mains test socket (LN), SUB1 \leftrightarrow P/S, TC1

10.6 Differential Leakage current

Differential leakage current

	Range	Resolution	Accuracy
Idiff	0.00 mA 19.99 mA	0.01 mA	±(3 % of reading + 5 D)

Power (active)

	Range	Resolution	Accuracy
	0.00 W19.99 W	0.01 W	\pm (5 % of reading + 5 D)
	20.0 W199.9 W	0.1 W	\pm 5 % of reading
	200 W 1999 W	1 W	\pm 5 % of reading
	2.00 kW 3.70 kW	10 W	± 5 % of reading

Operating range (acc. to EN 61557-16)0.19 mA ... 19.99 mA Frequency response of measuring circuit.....complies with EN 61010 - Figure A1 Influence of load current.......< 0.02 mA/A

Test terminals:	
Function	Connections
Differential leakage	Mains test socket (LN), TC1

10.7 PE leakage current

PE leakage current

	Range	Resolution	Accuracy
lpe	0.00 mA 19.99 mA	0.01 mA	±(3 % of reading + 3 D)

Power (active)

1 01101 (400			
	Range	Resolution	Accuracy
Р	0.00 W19.99 W	0.01 W	\pm (5 % of reading + 5 D)
	20.0 W199.9 W	0.1 W	\pm 5 % of reading
	200 W 1999 W	1 W	\pm 5 % of reading
	2.00 kW 3.70 kW	10 W	\pm 5 % of reading

Operating range (acc. to EN 61557-16)0.12 mA ... 19.99 mA Frequency response of measuring circuit.....complies with EN 61010 - Figure A1

Test terminals:

Function	Connections
PE leakage	Mains test socket, TC1

10.8 Touch leakage current

Touch leakage current

	Range	Resolution	Accuracy
Itou	0.00 mA 19.99 mA	0.01 mA	±(3 % of reading + 3 D)

Power (active)

	Range	Resolution	Accuracy
	0.00 W19.99 W	0.01 W	\pm (5 % of reading + 5 D)
	20.0 W199.9 W	0.1 W	\pm 5 % of reading
P	200 W 1999 W	1 W	± 5 % of reading
	2.00 kW 3.70 kW	10 W	± 5 % of reading

Operating range (acc. to EN 61557-16)0.12 mA ... 19.99 mA Frequency response of measuring circuit.....complies with EN 61010 - Figure A1

Output:

Function	Connections
Touch leakage	Mains test socket \leftrightarrow P/S, TC1

10.9 Power

Power (active)

	Range	Resolution	Accuracy
	0.00 W19.99 W	0.01 W	\pm (5 % of reading + 5 D)
П	20.0 W199.9 W	0.1 W	± 5 % of reading
	200 W 1999 W	1 W	± 5 % of reading
	2.00 kW 3.70 kW	10 W	± 5 % of reading

Power (apparent)

	Range	Resolution	Accuracy
	0.00 VA19.99 VA	0.01 VA	±(5 % of reading + 10 D)
c	20.0 VA199.9 VA	0.1 VA	\pm 5 % of reading
3	200 VA 1999 VA	1 VA	\pm 5 % of reading
	2.00 kVA3.70 kVA	10 VA	± 5 % of reading

Power (reactive)

	Range	Resolution	Accuracy
	0.00 VAr19.99 VAr	0.01 VAr	±(5 % of reading + 10 D)
0	20.0 VAr199.9 VAr	0.1 VAr	\pm 5 % of reading
Q	200 VAr 1999 VAr	1 VAr	\pm 5 % of reading
	2.00 kVAr3.70 kVAr	10 VAr	± 5 % of reading

Power factor

	Range	Resolution	Accuracy
PF	0.00i 1.00i 0.00c 1.00c	0.01	\pm (5 % of reading + 5 D)

Total Harmonic Distortion (voltage)

	Range	Resolution	Accuracy
THDU	0.0 % 99.9 %	0.1 %	\pm (5 % of reading + 5 D)

Total Harmonic Distortion (current)

	Range	Resolution	Accuracy
THDI	0 mA999 mA	1 mA	\pm (5 % of reading + 5 D)
	1.00 A 16.00 A	10 mA	\pm (5 % of reading)

Cosinus Φ

	Range	Resolution	Accuracy
Cos Phi	0.00i 1.00i 0.00c 1.00c	0.01	\pm (5 % of reading + 5 D)

Voltage

	Range	Resolution	Accuracy
	0.0 V 199.9 V	0.1 V	±(3 % of reading + 10 D)
0	200 V 264 V	1 V	\pm 3 % of reading

Current

	Range	Resolution	Accuracy
	0 mA999 mA	1 mA	\pm (3 % of reading + 5 D)
1	1.00 A 16.00 A	10 mA A	\pm 3 % of reading

Accuracy is valid within $0.5c \le PF \le 0.8i$

Test terminals:

Function	Connections
Power	Mains test socket, TC1

10.10 Leak's & Power

Power (active)

	Range	Resolution	Accuracy
	0.00 W19.99 W	0.01 W	\pm (5 % of reading + 5 D)
Р	20.0 W199.9 W	0.1 W	\pm 5 % of reading
P	200 W 1999 W	1 W	\pm 5 % of reading
	2.00 kW 3.70 kW	10 W	\pm 5 % of reading

Power (apparent)

	Range	Resolution	Accuracy
	0.00 VA19.99 VA	0.01 VA	±(5 % of reading + 10 D)
<u> </u>	20.0 VA199.9 VA	0.1 VA	\pm 5 % of reading
5	200 VA 1999 VA	1 VA	\pm 5 % of reading
	2.00 kVA3.70 kVA	10 VA	± 5 % of reading

Power (reactive)

	Range	Resolution	Accuracy
	0.00 VAr19.99 VAr	0.01 VAr	±(5 % of reading + 10 D)
	20.0 VAr199.9 VAr	0.1 VAr	\pm 5 % of reading
Q	200 VAr 1999 VAr	1 VAr	\pm 5 % of reading
	2.00 kVAr 3.70 kVAr	10 VAr	± 5 % of reading

Power factor

	Range	Resolution	Accuracy
PF	0.00i 1.00i 0.00c 1.00c	0.01	\pm (5 % of reading + 5 D)

Total Harmonic Distortion (voltage)

	Range	Resolution	Accuracy
THDU	0.0 % 99.9 %	0.1 %	\pm (5 % of reading + 5 D)

Total Harmonic Distortion (current)

	Range	Resolution	Accuracy
THDI	0 mA999 mA	1 mA	\pm (5 % of reading + 5 D)
	1.00 A 16.00 A	10 mA	\pm (5 % of reading)

Cosinus Φ

	Range	Resolution	Accuracy
Cos Phi	0.00i 1.00i 0.00c 1.00c	0.01	\pm (5 % of reading + 5 D)

Voltage

	Range	Resolution	Accuracy
	0.0 V 199.9 V	0.1 V	±(3 % of reading + 10 D)
U	200 V 264 V	1 V	±3 % of reading

Current

	Range	Resolution	Accuracy
	0 mA999 mA	1 mA	\pm (3 % of reading + 5 D)
1	1.00 A 16.00 A	10 mA	\pm 3 % of reading

Differential leakage current

	Range	Resolution	Accuracy
Idiff	0.00 mA 19.99 mA	0.01 mA	\pm (3 % of reading + 5 D)

Operating range (acc. to EN 61557-16)0.19 mA ... 19.99 mA Frequency response of measuring circuit.....complies with EN 61010 - Figure A1 Influence of load current......< 0.02 mA/AAccuracy is valid within $0.5c \le PF \le 0.8i$

Touch leakage current

	Range	Resolution	Accuracy
Itou	0.00 mA 19.99 mA	0.01 mA	\pm (3 % of reading + 3 D)

Operating range (acc. to EN 61557-16)0.12 mA ... 19.99 mA Frequency response of measuring circuit......complies with EN 61010 - Figure A1

Test terminals:

Function	Connections
Power	Mains test socket, TC1
Differential leakage	Mains test socket (LN), TC1
Touch leakage	Mains test socket \leftrightarrow P/S, TC1

10.11 Discharging time

Discharging time

	Range	Resolution	Accuracy
t	0.0 s 9.9 s	0.1 s	\pm (5 % of reading + 2 D)

Peak voltage				
		Range	Resolution	Accuracy
	Up	0 V 550 V	1 V	±(5 % of reading + 3 D)

Operating range (acc. to EN 61557-14)	0.8 s 9.9 s
High limits	1 s, 5 s
Threshold voltage	
Input resistance	48 MΩ
Max. load current (Output = Socket)	
Automatic disconnection at LILN if DUT (De	vice Under Teet) is connected to me

Automatic disconnection at $\mathsf{ULN}_{\mathsf{peak}}$ if DUT (Device Under Test) is connected to mains test socket.

Test terminals		
Function	Connections	
Discharging time External	$DISCH1 \leftrightarrow DISCH2$	
Discharging time Socket	Mains test socket (L,N), TC1	

10.12 General data

Power supply

Supply voltage, frequency	
Supply voltage tolerance	±10 %
Max. power consumption	
Max. power consumption	
Mains supply overvoltage category	CAT II / 300V
Altitude	≤ 2000 m

Measuring categories

DISCH1 / DISCH2	CAT II / 600 V
ISO(+) SUB1 / ISO(-) SUB2	
P1, C1 / P2, C2	
P/S	CAT II / 300 V
TC1	CAT II / 300 V
Mains test socket	CAT II / 300 V
Altitude	≤ 2000 m

Protection classifications

Power supply	Class I
HV output	
Pollution degree	2
Degree of protection	
• •	IP 40 (open case)
Case	Shock proof plastic / portable
INPUTs	24 Vmax, earthed
OUTPUTs	24 Vmax, earthed
Display	Colour TFT display, 4.3 inch, 480 x 272 pixels

Communication

Memory	depends on microSD card size
RS232 interfaces	
USB 2.0	
Bluetooth	
Ethernet	
	Static IP (manual)

I/Os

Inputs	DB9 connector (24 V max)
	DB9 connector (NO relays, 24 V max, 1.5 A max)

Dimensions (wxhxd):	43.5 cm × 29.2 cm × 15.5 cm
Weight	approximately 17 kg

Reference conditions

Reference temperature range:	15 °C 35 °C
Reference humidity range:	35 % 65 % RH

Operation conditions

Working temperature range:	0 °C +40 °C
Maximum relative humidity:	85 % RH (0 °C 40 °C), non-condensing

Storage conditions

Temperature range:	10 °C +60 °C
Maximum relative humidity:	90 % RH (-10 °C +40 °C)
· · · · · · · · · · · · · · · · · · ·	

Accuracies apply for 1 year in reference conditions. Temperature coefficient outside these limits is 0.2 % of measured value per °C plus 1 digit, otherwise noted.

Fuses

2 x T 16 A / 250 V, 32 mm \times 6.3 mm / 1500 A (protection of mains test socket) 2 x T 5 A / 250 V, 20 mm \times 5 mm / 1500 A (instrument protection)

Appendix A - Structure objects in C.A 6165

Symbol	Default name	Description
>_	Node	Node
Q	Project	Project
9	Location	Location
	Element	Universal element
2	Appliance	Appliance (basic description)
A	Appliance FD	Appliance (full description)
1	Machine	Electrical machine
\$ 8	Switchgear	Switchgear
	Level1	1st sub-level of machine / switchgear
	Level 2	2nd sub-level of machine / switchgear
	Level 3	3rd sub-level of machine / switchgear

Structure elements used in Memory Organizer are instrument's Profile dependent.

Appendix B - Profile Notes

There are no specific profile notes for C.A 6165 .

Appendix C - Print labels and write / read RFID / NFC tags

The instrument supports different printers and two tag formats (PAT and Generic); listed parameters setting is described in chapter 4.6.9 Devices.

Tag content can be presented as text only or arranged as text area and machine-readable code area – QR code – in addition.

The instrument supports RFID / NFC reader / writer device, tag type supported is NTAG216.

Please check with Chauvin Arnoux or distributor which printers and labels are supported in your instrument.

C.1 PAT tag format

It is intended for tagging of individual appliance with Auto Sequence® test data. To start printing, Auto Sequence® should be finished and saved or reopened from memory structure.

Label type is simple, containing text area only, available data are:

- Appliance ID
- Appliance name
- Test date
- Retest date
- Auto Sequence® test status

• User name (who currently performed test or who performed saved test, if printed from memory)

Following table describe tag content arrangement and its data for supported form size and chosen label type.

Label type	Form size W x H (mm)	Tag content arrangement	Label data
Simple	50x25,5	Text	Appliance ID, appliance name, test status, test or retest date, user name

Notes:

- Data not available will not be printed on the label.
- Test or Retest date: it is set in the General Settings => Devices => Writing devices menu.
- If Auto Sequence® was modified, its short code is marked with asterisk (*).

C.2 Generic tag format

It is intended for tagging structure objects which could be tested. In addition to test result data, test object location within structure is marked. Label printing can be started from selected structure object even if no Auto Sequence® is associated with it, or from finished Auto Sequence® saved under it.

Tag data presented in text area are:

- Parent structure object ID (name) (← Object_name)
- Auto Sequence® short test code (if printing from Auto Sequence®; if printing from object field is omitted)
- Object ID (name)
- Test date (|→ DD.MM.YYYY) or Retest date (→| DD.MM.YYYY), which one is selected in General Settings
 => Devices => Writing devices menu
- Status (printing from object: overall status of all tests appended to the object or sub-structure objects; printing from Auto Sequence®: its status)
- User name (Printing from Auto Sequence: user who performed test; printing from object: current signed-in user)

Tag data presented in machine-readable area are:

- Parent structure object ID (name)
- Auto Sequence® short test code (if printing from Auto Sequence®; if printing from object field is omitted)
- Object ID (name)
- Test date
- Test period (from appliance description)
- Auto Sequence® status (field is omitted, if not printing from Auto Sequence®)
- > Object status (overall status of all tests appended to the object or sub-structure objects)
- User name (Printing from Auto Sequence®: user who performed test; printing from object: currently signed-in user)

Following table describes tag content arrangement and its data for supported label form size.

Form size W x H (mm)	Tag content arrangement	Data
	Text	Parent object name, Test code, Object ID, test or retest date, status,
		user
50 x 25.5	QR	Parent object name, Test code, Object ID, test date, test period,
		Auto Sequence® status, Object status, user.

Notes:

- > Data not available will not be printed on the label.
- Object without appended Auto Sequence® test has no status!
- If Auto Sequence® was modified, its short code is marked with asterisk (*).
- Object status depends on all measurements (Auto Sequences® or Single tests) appended to the object or substructure objects, see chapter 5.1.2.1 Measurement status indication under the Structure object for details.

Following table describes data content written on RFID / NFC tag.

RFID / NFC tag type	Data
NTAG216	Parent object name, Test code, Object ID, test date, test period, Auto Sequence® status, Object status, user.

Appendix D - Default list of Auto Sequences®

Pre-programmed DEMO Auto Sequences®

No.	Name	Description
1		This Auto Sequence [®] is just for demonstration of manipulation of Auto Sequence [®] operation.
2	DEMO_2	This Auto Sequence [®] is just for demonstration of manipulation of Auto Sequence [®] operation.

Appendix E - Programming of Auto Sequences[®] on MT Link

The Auto Sequence[®] Editor is a part of the MT Link software. In Auto Sequence[®] Editor, Auto Sequences[®] can be preprogrammed and organized in groups, before uploaded to the instrument.

E.1 Auto Sequence® Editor workspace

	>>>	
To enter Auto Sequence® editor's workspace, select		
Sequence® editor workspace is devided in four main ar		
Sequence [®] is displayed. In the middle part of the works		
shown. On the right side, list of available single tests	and list of flow co	ommands 4 are shown.

Single test area contains three tabs, Measurements Inspections and Custom Inspections tab. Custom Inspections and their tasks are programmed by user.

۵	DEMO Appliance test.atmpx - Auto Sequence® Editor				
	to Sequence® Commun to Sequence® Delete Download		or		
DEMO Appliance test atmpx × Auto Sequence® group Image: Class I Image: Class II Image: Class II	Auto Sequence® code: PL001	Appliance class I test Class I appliance safety test: Isolation Continuity Differential leakage	Single test Measurement Inspections Continuity Differential Leakage Discharging Time HV AC HV AC programmable HV DC Flow Commands	Custom Inspections	
	BUZZER mode R iso PAUSE SINGLE TEST OPERATION AFTER END OF TEST	0	PAUSE OUTPUT STATE WAIT INPUT mode LAMPS PassFail mode LAMPS HV mode		
	Continuity SINGLE TEST OPERATION AFTER END OF TEST Differential Leakage ONIONE TEST	•	BUZZER mode EXTERNAL OK KEY mode NO NOTIFICATION mode APPLIANCE INFO FLOW PROTOCOL		

Figure E.1: Auto Sequence® editor workspace

An Auto Sequence[®] begins with Name, Description and Image, followed by the first step (Header), one or more measuring steps and ends with the last step (Result). By inserting appropriate Single tests and Flow commands and setting their parameters, arbitrary Auto Sequences[®] can be created.

Header
APPLIANCE INFO
BUZZER mode
Continuity 🔅
PAUSE
SINGLE TEST
OPERATION AFTER END OF TEST
Result
PAUSE
RESULT SCREEN

Figure E.2: Example of an Auto Sequence® header

Figure E.3: Example of a measurement step

Figure E.4: Example of an Auto Sequence® result

E.2 Managing of Auto Sequence[®] groups

The Auto Sequence[®] can be divided into different user defined Auto Sequence[®] groups. Each Auto Sequence[®] group is stored in a file. More files can be opened simultaneously in Auto Sequence[®] editor. Within Auto Sequence[®] Group, tree structure can be organized, with folders / subfolders containing Auto Sequence[®]. The three structure of currently active Auto Sequence[®] Group is displayed on the left side of the Auto Sequence[®] editor workspace, see *Figure E.5.*




Figure E.5: Auto Sequence[®] Group tree organization

Operation options on Files and Auto Sequence[®] Group are available from menu bar at the top of Auto Sequence[®] editor workspace.

File operation options:

	Opens a file (Auto Sequence [®] Group).
	Creates a new file (Auto Sequence [®] Group).
-	Saves / Saves as the opened Auto Sequence [®] Group to a file.
\bigotimes	Closes the file (Auto Sequence [®] Group).

Group of Auto Sequences® view options:

>	Expand all folders / subfolders / Auto Sequences [®] .
	Collapse all folders / subfolders / Auto Sequences [®] .
Q	Toggle between Search by name within Auto Sequence® group and normal view. See chapter <i>E.2.2 Search within selected Auto Sequence</i> [®] group for details.

Auto Sequence[®] Group operation options (also available by right clicking on Folder or Auto Sequence[®]):

	Adds a new folder / subfolder to the group.	
	Adds a new Auto Sequence [®] to the group.	
×	Deletes: - the selected Auto Sequence [®] - the selected folder with all subfolders and Auto Sequences [®]	

Right click on the selected Auto Sequence® or Folder opens menu with additional possibilities:

Ø	Auto Sequence [®] : Edit Name, Description and Image (see <i>Figure E.6</i>). Folder: Edit folder name
	Auto Sequence [®] : Copy to clipboard
	Folder: Copy to clipboard including subfolders and Auto Sequences®
cila.	Auto Sequence [®] : Paste it to selected location
	Folder: Paste it to selected location
2	Auto Sequence®: Create shortcut to selected Auto Sequence®

Double click on the object name allows it name edit:

DOUBLE CLICK	Auto Sequence [®] name: Edit Auto Sequence [®] name
	Folder name: Edit folder name
	Portable / Handheld Equipment

Drag and drop of the selected Auto Sequence[®] or Folder / Subfolder moves it to a new location:

DRAG & DROP	"Drag and drop" functionality is equivalent to "cut" and "paste" in a single move.
-------------	--

E.2.1 Auto Sequence[®] Name, Description and Image editing

When EDIT function is selected on Auto Sequence[®], menu for editing presented on *Figure E.6* appear on the screen. Editing options are:

Name: Edit or change the name of Auto Sequence®.

Description: Any text for additional description of Auto Sequence[®] can be entered.

Image: Image presenting Auto Sequence® measuring arrangement can be entered or deleted.

P	Enters menu for browsing to Image location.
x	Deletes the Image from Auto Sequence®.

Name	DEMO1 Live Test	
Description	Mains voltage is applied on DUT	-
		Ŧ
Image	P Class 1 Equipment.bmp	×
	ОК Са	ancel

Figure E.6: Editing the Auto Sequence® Name, Description and Image

E.2.2 Search within selected Auto Sequence[®] group

When subscription is selected, Search menu as presented on *Figure E.7* appear on the screen. By entering the text into search box, found results are automatically highlighted with yellow background. Search functionality is implemented in Folders, Subfolders and Auto Sequences[®] of selected Auto Sequences[®] Group. Search functionality is case sensitive. Search text can be cleared by selecting the Clear button.




Figure E.7: Example of Search result within Auto Sequence® group

E.3 Elements of an Auto Sequence®

E.3.1 Auto Sequence[®] steps

There are three kinds of Auto Sequence® steps.

Header

The Header step is empty by default. Flow commands can be added to the Header step.

Measurement step

The Measurement step contains a Single test and the Operation after end of test flow command by default. Other Flow commands can also be added to the Measurement step.

Result

The Result step contains the Result screen flow command by default. Other Flow commands can also be added to the Result step.

E.3.2 Single tests

Single tests are the same as in MT LinkMeasurement menu. Limits and parameters of the measurements can be set. Results and sub-results can't be set.

E.3.3 Flow commands

Flow commands are used to control the flow of measurements. Refer to chapter *E.5 Description of flow commands* for more information.

E.3.4 Number of measurement steps

Often the same measurement step has to be performed on multiple points on the device under test. It is possible to set how many times a Measurement step will be repeated. All carried out individual Single test results are stored in the Auto Sequence[®] result as if they were programmed as independent measuring steps.

E.4 Creating / modifying an Auto Sequence®

If creating a new Auto Sequence[®] from scratch, the first step (Header) and the last step (Result) are offered by default. Measurement steps are inserted by the user.

Options:

Adding a measurement step	By double clicking on a Single test a new measurement step will appear as the last of measurement steps. It can also be dragged and dropped on the appropriate position in the Auto Sequence [®] .
Adding flow commands	Selected flow command can be dragged from the list of Flow commands and dropped on the appropriate place in any Auto Sequence [®] step.
Changing position of flow command within measurement step	By a click on an element and use of 🦲 , 🕐 keys.
Viewing / changing parameters of flow commands or single tests.	By a double click on the element.
Setting number of measurement step repetitions	By setting a number in the field.
	Note:
	Up to 999 step repetitions can be set.
1	

Right click on the selected measurement step / flow command:

		Copy – Paste before
3	Сору	A measurement step / flow command can be copied and pasted above selected location on the same or on another Auto Sequence [®] .
	Paste before	Copy – Paste after
	Paste after	A measurement step / flow command can be copied and pasted under selected location on the same or on another Auto Sequence [®] .
TEST	Delete	
-		Delete
		Deletes the selected measurement step / flow command.

E.5 Description of flow commands

Double click on inserted Flow Command opens menu window, where text or picture can be entered, external signalling and external commands can be activated and parameters can be set.

Flow commands Operation after end of test and Results screen are entered by default, others are user selectable from Flow Commands menu.

Pause

A Pause command with text message or picture can be inserted anywhere in the measuring steps. Warning icon can be set alone or added to text message. Arbitrary text message can be entered in prepared field Text of menu window.

Parameters:

Pause type	Show text and/or warning (Check to show warning icon) Show picture (P browse for image path)
Duration	Number in seconds, infinite (no entry)

Output state

Sets outputs OUT_1, OUT_2, OUT_3, and OUT_4 on OUTPUT port. Following settings of this command are ignored:

• OUT_1 and OUT_2 while Lamps HV mode is enabled.

OUT_3 and OUT_4 while Lamps Pass / Fail mode is enabled.

All outputs are single normally opened relay contacts if not checked in Menu Output pins window.

Parameters:

OUT_1	Set closed relay contact between OUTPUT pins 4 and 9		
OUT_2	Set closed relay contact between OUTPUT pins 3 and 8		
VUT_3	Set closed relay contact between OUTPUT pins 2 and 7		
OUT_4	Set closed relay contact between OUTPUT pins 1 and 6		
OUT_5			
OUT_6			
OUT_7	Applicable only when using CE Adapter A 1460		
OUT_8			

Wait input mode

Reads input condition on pins IN_2, IN_3, IN_4 and IN_5 on INPUT port. Input must be high to proceed with the Auto Sequence[®].

Parameters

State	On – enables Wait input mode; set active INPUT from Input pins menu Off – disables Wait input mode		
IN_2	IN_2 reading condition on INPUT pin 6 is active		
🗹 IN_3	IN_3 reading condition on INPUT pin 7 is active		
✓ IN_4	IN_4 reading condition on INPUT pin 8 is active		
IN_5	IN_5 reading condition on INPUT pin 4 is active		

Lamps HV mode

Drives external lamps through OUT_1 and OUT_2 outputs. Works only in HV & HV programmable functions.

- Red lamp (OUT_1) ON means that the instrument is ready for HV test. Red lamp turns on before first flow command in step that contains HV test. Red lamp turns off after end of the HV test.
- Green lamp (OUT_2) blinking means that high voltage will be applied to WITHSTANDING (HV(~+) and HV(~)) test terminals as soon as all input conditions will be fulfilled.
- Green lamp (OUT_2) ON means that dangerous voltage is present at WITHSTANDING (HV(~+) and HV(~-)) test terminals. Green lamp turns on before the measurement and turns off after the measurement.

While Lamps HV mode command is enabled the settings of Drive output command for OUT_1 and OUT_2 is ignored.

Parameters

State	On – enables Lamps HV mode	
	Off – disables Lamps HV mode	

Lamps Pass / Fail mode

Drives external lamps through OUT_3 and OUT_4 outputs.

During measurement the lights reflect status icon in single test.

After measurement

- Blue lamp (OUT_3) lights ON when test has passed. Lamp is lit until next step is started.
- Yellow lamp (OUT_4) lights ON when test has failed. Lamp is lit until next step is started.
- Lights turn off at the beginning of next step.

While Lamps Pass / Fail mode command is enabled the settings of Drive output command for OUT_3 and OUT_4 is ignored.

Parameters

State	On – enables Lamps Pass / Fail mode	
	Off – disables Lamps Pass / Fail mode	

Buzzer mode

Passed or failed measurement is indicated with beeps.

- Pass double beep after the test
- Fail long beep after the test

Beep happens right after single test measurement.

Parameters

State	On – enables Buzzer mode
	Off – disables Buzzer mode

External TEST / OK key mode

Instrument enables external TEST / OK key (OK / ENTER / TEST / HV TEST) by activating INPUT pin 5 reading condition. Functionality of the EXTERNAL OK KEY mode is the same as of the OK / ENTER / TEST / HV TEST key.

Parameters

State	On – enables External TEST / OK key mode (INPUT pin 5 is active)
	Off – disables External TEST / OK key mode

No notifications mode

Instrument skips pre-test warnings (see C.A 6165 User Manual, chapter 4.4 Symbols and messages for more information).

Parameters

State	On – enables No notifications mode
	Off – disables No notifications mode

Appliance info

Instrument enables to automatically add the appliance name to the Auto Sequence®.

Parameters

Repeat Setting	Repeat:	The same Appliance ID will be offered each time if the same Auto Sequence [®] is carried out successively in a loop.		
	Increment:	A four digit number will be added to the Appliance ID and incremented each time if the same Auto Sequence [®] is carried out successively in a loop.		
Appliance type	Selects the type	Selects the type of the appliance (Appliance, Appliance_FD)		
Default Appliance ID	Enter default Ap	Enter default Appliance ID		
Appliance name	Enter Appliance name.			
	Options:			
	 Editable – allows Appliance name to be modified while running Auto Sequence Menu with a list of Appliance names and possibility to enter custom Appliance name offered within the test. Not editable – Default Appliance name is used. Appliance name cannot be modified while running Auto Sequence®. 			
Retest period	Retest period in months.			
	Options:			
	Editable – allows Retest period to be modified while running Auto Sequen Numeric keypad for entering custom Retest period is offered within the test.			
	Not editable – Default Retest period is used. Retest period cannot be modified wh running Auto Sequence®.			

Note

• This flow command is active only if Auto Sequence[®] is started from the Auto Sequences[®] Main menu.

Inspection Expert mode

If Inspection Epert mode flow command is set, the Visual inspection screen and Functional inspection screen within Auto Sequence[®] are displayed for 1 second and an overall PASS is automatically applied at the end of test. In between, the automatic procedure can be stopped and statuses can be applied manually.

Inspection Expert mode is disabled by default.

Parameters

State	On – enables automatic settings of tickers in Visual and Functual tests.
	Off – disables automatic settings of tickers in Visual and Functional tests.

Flow Protocol

This flow command controls commands for communication with external device for the control of the flow of Auto Sequence[®].

Parameters

Communication settings	Selects the port for communication with the external device. - RS232(PC) - USB		
Flow settings	Commands for comm (industrial PC for example	nunication with external device mple)	
	Proceed	Send string: Proceed	
		Description: If Proceed Flow setting is enabled, implementation of Auto Sequence [®] on instrument can be automatically controlled by external device by using Proceed string command. Command works in parallel with OK / ENTER / TEST / HV TEST keys and the EXTERNAL TEST / OK key mode. Proceed Flow setting is disabled by default.	
	End + Status	Recived strings: End - pass End - fail End - none End - empty	
		Description: Instrument sends string to external device at the end of each Measurement step. End + Status Flow setting is disabled by default.	
	Alarm	Recived string: Alarm	
		Description: Instrument sends "Alarm" string to external device if "empty" status is detected and if both conditions -"Fail" status at the end of measurement step and flow command OPERATION AFTER END OF TEST – fail is set to "manual". Alarm Flow setting is disabled by default.	

Operation after end of test This flow command controls the proceeding of the Auto Sequence[®] in regard to the measurement results.

Parameters

Operation after end of test – pass	The operation can be individually set for the case the measurement passed, failed or ended without a status.	
– fail – no status	Manual:	The test sequence stops and waits for apropriate command (TEST key, external command) to proceed.
	Auto:	The test sequence automatically proceeds.

Result screen

This flow command controls the proceeding after the Auto Sequence® has ended.

Parameters

Auto Save	Auto Sequence [®] results are stored in the momentary workspace. A new Node with the month and year will be created. Under the Node Auto Sequence [®] results or (if Appliance info flow command is set) a new appliance and Auto Sequence [®] results will be stored.
	Up to 100 Auto Sequence [®] results or appliances can be automatically stored under the same node. If more results / appliances are available, they are split to multiple nodes.
	Local Save Flow setting is disabled by default.
Auto Print	Auto Sequence® results are automatically printed.

Notes

This flow command is active only if Auto Sequence[®] is started from the Auto Sequences[®] Main menu (not from Memory organizer).

E.6 Custom Inspections programming

Arbitrary set of tasks dedicated to specific user defined Inspections can be programmed with application of Custom Inspection Editor Tool, accessible from Auto Sequence® Editor workspace. Custom Inspections are stored in dedicated file *.indf with user defined name. For application of Custom Inspections as a single test within Auto Sequence® group, appropriate file containing specific Custom Inspection should be opened first.

E.6.1 Creating and editing Custom Inspections

1

2

Custom Inspection Editor workspace is entered by selecting <u>Custom Inspection Editor</u> icon from Auto Sequences® main menu. It is divided in two main areas, as presented on *Figure E.8: Custom Inspection Editor workscpace*.

X



Name of Custom Inspection Item tasks and Type of Item Pass / Fail checkbox marking

File Inspection					
Add New					
X Demove					
Open New Save					
Extension cord Custom Inspections.ind f \times					
Vame	Scope	Na	me		Туре
Visual PRCD protected extension cord	Visual	⊿	No	visible injury	Pass_Fail_Empty
Functional PRCD protected extension cord	Functional			Housing condition	Pass_Fail_Checked_Empty
Visual Multi-outlet extension cord Visual				Switches condition	Pass_Fail_Checked_Empty
Functional Multi-outlet extension cord	Functional		⊿	Connections	Pass_Fail_Checked_Empty
Visual Outdoor extension cord	al Outdoor extension cord Visual			Cable no twists, no injury	Pass_Fail_Checked_Empty
unctional Outdoor extension cord Functional				Plug no corrosion, no injury	Pass_Fail_Checked_Empty
				Socket no corrosion, no injury	Pass_Fail_Checked_Empty
		⊿	Mar	king	Pass_Fail_Empty
			⊿	PRCD type	Pass_Fail_Checked_Empty
				ldn	Pass_Fail_Checked_Empty
			⊿	Operating conditions	Pass_Fail_Empty
				Nominal voltage	Pass_Fail_Checked_Empty
				Nominal current	Pass_Fail_Checked_Empty
				Environment protection	Pass_Fail_Checked_Empty
				Applied standards	Pass_Fail_Empty

Figure E.8: Custom Inspection Editor workscpace

Custom Inspection Editor Main menu options:

	Opens existing Custom Inspection Data file. By selecting, menu for browsing to location of *.indf file containing one or more Custom Inspections data appear on the screen. Selected file is opened in dedicated tab marked with file name.
	Creates a new Custom Inspection Data file. New tab with empty workspace is opened. Default name of the new tab is <i>Inspection Data File</i> ; it could be renamed during Save procedure.
•	Saves / Saves as Custom Inspection Data file opened on active tab. Menu for browsing to the folder location and editing of file name is opened. Browse to the location, confirm overwriting, if file already exists or edit file name to save it as a new Custom Inspection Data file.
	Add New Custom Inspection. New inspection with default name <i>Custom Inspection</i> and default scope <i>Visual</i> appear on the editor workspace. It contains one Item task with default name <i>Custom Inspection</i> and default Type <i>Pass_Fail_Checked_Empty</i> . Default Name and Type can be edited – changed.



Remove selected custom inspection. To select inspection, click to the inspection Name field. To remove it, select icon from editor main menu. Before removal, user is asked to confirm deletion.

Edit Name and Scope of Inspection

Visual PR	on La	
Functiona	5	Undo
Visual Mu Functiona	\aleph	Cut
	гD	Сору
Visual Ou		
Functiona	-	Paste
	X	Delete
	_	Select All
Scope		
Visual		-

Inspection Name edit:

Click to the Inspection Name field to start editing it.

Drag cursor, with left mouse button pressed, to select letters and words. Position cursor and double-click to select word of the name. Actions could be performed with keyboard also.

Press right mouse button to activate Edit menu and select appropriate action as presented on the left figure. Menu is case sensitive; options currently not available are greyed out.

Inspection Scope edit:

Click to Inspection Scope field to open selection menu presented on left figure. Options: **Visual** is intended for observation of test object **Functional** allows functional test of observed object

Edit Item task structure of Inspection

vai	ne									
4	Item task Child Item task		Item tasks of the selected Inspection are listed in Name column on the right side of Editor workspace.							
	-		Each Item task can have Child Item tasks, Child Item can have its own Child Iter							
	Child Item task Child Item task Child Item task Item task		tasks and so on. Arbitrary tree structure of Item tasks and subtasks can be built as presented on							
								left figure.		
							lai	me		ADD New Item task procedure:
			Item task C Add New Add New Add New child Remove selected		 Position cursor above Item task Name and apply right mouse click to select Item task and open menu with options: Add New: new Item task is added on the top tree level Add New Child: new child Item task is added under selected Item Remove selected: delete selected Item task with all subtasks 					
	Item task		Default Name of New Item task is <i>Custom Inspection</i> , default Type Pass_Fail_Checked_Empty and both can be edited – changed.							
Var	ne									
⊿ Item task		ask	Item tasks containing Child Item tasks are marked with triangle in front of their							
	Ch	nild Item task	Name.							
⊿	⊿ Ch	nild Item task	Click on triangle mark:							
	Child Item task		collapse Item task tree structure							
	Child Item task Item task		expands Item task tree structure							

Edit Name and Type of Item task

Name							
⊿ No	o visible injury						
	Housing condition			Edit Name of Item task:			
▲ ▲ M: ▷	Switches on Connection Cable Plug r Sock arking PRCD typ Operating Applied s) Undo Cut Copy Paste	ry	Click to the Item task Name field to start editing it. Drag cursor, with left mouse button pressed, to select letters and words. Position cursor and double-click to select word of the name. Actions could be performed with keyboard also. Press right mouse button to activate Edit menu and select appropriate action as presented on the left figure. Menu is case sensitive; options currently not available are greyed out.			
Type Pass	Fail_Empty			Edit Tuna of Itom taak			
Pass	Fail_Checked_E	impty		Edit Type of Item task:			
Pass_	Fail_Empty			Click to Item Type field to open selection menu presented on left figure. Selectable checkbox status assignment options are:			
			- 1	Pass_Fail_Checked_Empty: Pass, Fail, Checked, Empty (default)			
				Pass_Fail_Empty: Pass, Fail selection, Empty (default) value			
×							
_			- 11				

E.6.2 Applying Custom Inspections

Custom inspections can be applied in Auto Sequences®. Direct assignment of Custom inspection to the MT Linkstructure objects is not possible.

After custom created Inspection Data file is opened, available inspections are listed in Custom Inspections tab of Single test area of Auto Sequence® Editor, see chapter *E.1 Auto Sequence*® Editor workspace for details. Custom Inspection is added to Auto sequence as a Single test, see chapter *E.4 Creating / modifying an Auto Sequence*® for details.

Opening / changing Inspection Data File

Single test				
Measurement Inspections Custom Inspections	Position cursor within Custom inspections List area and apply mou right click to open Option menu:			
Custom Inspection sample01	S			
Custom Inspection sample02	Refresh: Refresh content of already opened Inspection Data file.			
Custom Inspection sample03	Browse for custom Inspection file:			
Browse for custom inspection file Refresh	Menu for browsing to folder location of new Inspection Data file is opened.			
Measurement Inspections Custom Inspections	After confirmation of selection, new Inspection Data file is opened and list of available Custom Inspections is changed.			
Visual PRCD protected extension cord	Note:			
Functional PRCD protected extension cord Visual Multi-outlet extension cord	 If MT LinkWork scope is changed, opened Inspection Data file 			
Functional Multi-outlet extension cord	remains active and available Custom Inspections remains			
Visual Outdoor extension cord				
Functional Outdoor extension cord	same.			

FRANCE

Chauvin Arnoux Group 190, rue Championnet 75876 PARIS Cedex 18 Tél : +33 1 44 85 44 85 Fax : +33 1 46 27 73 89 info@chauvin-arnoux.com www.chauvin-arnoux.com

INTERNATIONAL Chauvin Arnoux Group Tél : +33 1 44 85 44 38 Fax : +33 1 46 27 95 69

Our international contacts

www.chauvin-arnoux.com/contacts

